


# **WINGET**



# **Croker**

## **CUMFLOW RP850XD ROTATING PAN MIXER**

# **PARTS & OPERATION MANUAL**

**WINGET LIMITED  
PO BOX 41  
EDGEFOLD INDUSTRIAL ESTATE  
PLODDER LANE  
BOLTON  
LANCS  
BL4 OLS**

**Tel:++ 44 (0) 1204 854650  
Fax:++ 44 (0) 1204 854663  
crokersales@winget.co.uk  
parts@winget.co.uk  
service@winget.co.uk  
www.winget.co.uk**

# **INDEX**

## **SECTION 1      GENERAL INFORMATION**

- 1.1.            Company Details
- 1.2.            Important Notice
- 1.3.            Mixer Operational and Safety Requirements
- 1.4            Installation Drawing
- 1.5            Test Certificates (Where applicable)

## **SECTION 2      INSTALLATION AND OPERATING INSTRUCTIONS**

- 2.1.            Pre Installation Notes
- 2.2.            Installation Instructions
- 2.3.            Operating Instructions

## **SECTION 3      TECHNICAL SPECIFICATION AND MAINTENANCE**

- 3.1.            Technical Specification
- 3.2.            Shutdown Procedure and Maintenance
- 3.3.            Maintenance of Mixer
- 3.4.            Maintenance and Lubrication
- 3.5.            Lubrication Layout

## **SECTION 4      MIXER SPARE PARTS**

- 4.1.            General Arrangement of Parts and Top & Bottom Structures
- 4.2.            Pan Roller Assembly
- 4.3.            Door Control Assembly
- 4.4.            Pan Drive Assembly
- 4.5.            Pan Assembly
- 4.6.            Pan Door Assembly
- 4.7.            Discharge Blade Assembly
- 4.8.            Mixing Star Assembly
- 4.9.            Fixed Blade Assembly
- 4.10.          Layout of Guards
- 4.11.          Pan Sealing Arrangement
- 4.12.          Decals & Logo's

## **SECTION 5      OPTIONAL ANCILLIARY EQUIPMENT SPARE PARTS**

- 5.1            Arrangement of Winch Unit
- 5.2            Arrangement of Loader Runway
- 5.3            Arrangement Loading Hopper and Weigher
- 5.4            Arrangement of Whirler Motor Up
- 5.5            Arrangement of Whirler Motor Up 460Volt 3Ph 60Hz
- 5.6            Arrangement of Whirler Split Shaft

5.7	Wire Rope Renewal Procedure (Standard Loader)
5.8	Wire Rope Renewal Procedure (Bottom Discharge Loader)
5.9	Wire Rope Safety Notes
5.10	Pneumatic Oiler (Not available on all models)
5.11	Water System
5.12	0-100 Litre Flow Meter
5.13	1.5" BSP Water Spray Bar
5.14	Bottom Discharge Loader Runway Arrangement
5.15	Bottom Discharge Loading Hopper
5.16	Axle Assembly Bottom Discharge Hopper
5.17	Door Assembly Bottom Discharge Loading Hopper
5.18	Guide Shaft Assembly Bottom Discharge Loading Hopper
5.19	Pulley Bottom Discharge Loading Hopper
5.20	Side Roller Bottom Discharge Loading Hopper
5.21	Loader Frame Bottom Discharge Loading Hopper
5.22	Drive Assembly Bottom Discharge Loading Hopper

## SECTION 6      **ELECTRICAL SYSTEM**

6.1	Electrical Instructions
6.2	Wiring Diagrams (Where Applicable)
6.3	Component Listing (Where Applicable)
6.4	Interlock Switch Mounting (Where Applicable)

## SECTION 7      **PNEUMATIC SYSTEM**

7.1	Pneumatic Instructions – Shutdown Procedure
7.2	Circuit Diagrams

## SECTION 8      **MISCELLANEOUS**

8.1	Noise
8.2	Special Pan Covers and Inlets
8.3	Miscellaneous Items

## SECTION 9      **ELECTRONIC LOADCELL & READOUT BOX**

The contents of this handbook although correct at the time of publication, may be subject to alteration by the manufacturers without notice and Winget Limited can accept no responsibility for any errors or omissions contained within the following pages. Nor can we accept any liability whatsoever arising from the use of this manual howsoever caused.

Winget Limited operate a policy of continuous product development. Therefore, some illustrations or text within this publication may differ from your machine

Winget Limited can accept no responsibility for incorrectly supplied spare parts unless the part number and a full description of the items required is given when the order is placed.

**NOTE**

Imperial fixings (bolts, setscrews, nuts, washers etc) have been progressively changed to Metric. If in doubt as to whether you have a Metric or Imperial fixing please order the metric items listed, i.e. bolt or setscrew and associated or flat and spring washers to replace the existing items.

**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 1**

**GENERAL INFORMATION**

## **COMPANY DETAILS AND GENERAL INFORMATION**

For any spares or service work, please contact:-

Winget Limited  
P.O. Box 41  
Edgefold Industrial Estate  
Plodder Lane  
Bolton  
Lancs U.K.  
BL4 OLS

Telephone No:	++ 44 (0)1204 854650
Facsimile No:	++ 44 (0)1204 854663
'E Mail'	<a href="mailto:crokersales@winget.co.uk">crokersales@winget.co.uk</a> <a href="mailto:parts@winget.co.uk">parts@winget.co.uk</a> <a href="mailto:service@winget.co.uk">service@winget.co.uk</a>

### **ORDERING SPARES**

To help us to complete your order promptly and correctly we need:-

- Machine type and serial number
- Description and quantity of parts required
- The full address to which the parts are to be sent

Winget Limited can accept no responsibility for incorrectly supplied spare parts unless the part number and a full description of the items required is given when the order is placed.

## **IMPORTANT NOTICE**

The CUMFLOW RP850XD is a high performance mixer

The following precautions are necessary to obtain the best results and to avoid damage to the MIXING STAR and PAN DRIVE

**ENSURE TRANSIT BAR AND RING ARE REMOVED FROM DOOR BEFORE STARTING MACHINE.**

### **AGGREGATES**

Strict control of graded aggregates must be maintained  
Maximum size 25mm

Oversize lumps of aggregate or rogue materials must be prevented from entering the Pan

### **MIXING STAR BLADES**

They are to a special shape and material to prolong wear life. They should not be modified in any way and only replaced with GENUINE 'CROKER' spares Obtained from **WINGET LIMITED**.

A daily check is advisable to ensure that the Blades/Wearing parts are secure and undamaged.

### **PAN RIM & BASE WEARING PLATES**

They must be replaced before excessive wear causes distortion.

### **MAXIMUM BATCH LOADS**

UNDER NO CIRCUMSTANCES should the Maximum Batch Loads quoted be exceeded nor should the mixer be or re-started when there is a mix in the Pan

### **MIXING PAN**

Ensure that the Mixing Pan is rotating concentrically and that the pan base is Rotating in horizontal place, otherwise damage may occur to the door mechanics.

## WARNING

THE MANUFACTURER ACCEPTS NO RESPONSIBILITY FOR ANY DAMAGE OR FAILURE RESULTING FROM OPERATIONAL MISUSE OR MALPRACTICE. ANY MODIFICATIONS TO THE MACHINE WILL AFFECT ITS WORKING PARAMETERS AND SAFETY FACTORS. REFER TO THE MANUFACTURERS BEFORE FITTING ANY NON STANDARD EQUIPMENT OR PARTS.

THE MANUFACTURERS ACCEPT NO RESPONSIBILITY FOR ANY MODIFICATIONS MADE AFTER THE MACHINE HAS LEFT THE FACTORY, UNLESS PREVIOUSLY AGREED IN WRITING. THE MANUFACTURERS WILL ACCEPT NO LIABILITY FOR DAMAGE TO PROPERTY, PERSONNEL OR THE MACHINE IF FAILURE IS BROUGHT ABOUT DUE TO SUCH MODIFICATIONS, OR THE FITMENT OF SPURIOUS PARTS.



**RP850XD**  
**OPERATIONAL AND SAFETY**  
**REQUIREMENTS**

**PRE-DELIVERY**

- 1.1 Drive coupling alignments, pan and star meshing of pan rack and drive gear.
- 1.2 Operating clearances star blade to pan. Fixed blade to pan wall.
- 1.3 Discharge blade to pan base.
- 1.4 Rollers to register ring.
- 1.5 Correct oil level in gearboxes. All grease points charged. Gear teeth greased.
- 1.6 Air system tested.
- 1.7 Door operation and seating.
- 1.8 No load test. Correct rotations.

**PRE INSTALLATION**

- 2.1 Check consignment.
- 2.2 Offload equipment using certified lifting gear of suitable capacity, by a competent person (see separate chart for nett weight).

**INSTALLATION**

- 3.1 Refer to contract arrangement and site instructions.
- 3.2 Mixer to be mounted on supports of adequate strength and rigidity to prevent undue vibration when mixing and securely bolted.
- 3.3 Mixer frame to be level on structure, add packers as required.
- 3.4 Check that pan is correctly seated on Rollers and that pan rack and drive gear are in correct mesh.
- 3.5 Check locating rollers to register ring.
- 3.6 Check operating clearances star blade to pan. Fixed blade to pan wall. Discharge blade to pan base. See maintenance section Ops Manual.

## **ELECTRICAL SERVICES**

Refer to wiring diagrams in Section 6. All wiring to be undertaken by competent electrician. **NOTE:** Electrical cables particularly those with copper conductors suffer from a condition known as ‘relaxation’ which may cause wiring to work loose over a period of time, it is recommended that the tightness of wiring connections and terminals are checked following the first month in service.

- 4.1 Refer to pneumatic circuit diagram in Section 7. Connect compressor. Supply compressed air 5.5 bars as required (80psi).
- 4.2 Refer to wiring diagram in Section 6 when connecting air control valves.
- 4.3 Remove transit bar and ring from door **BEFORE** starting mixer.
- 4.4 Ensure starters are mounted away from mixer on supports free of vibration.
- 4.5 Ensure starters are fitted with correct overloads – see technical specification power units.

## **OPERATION**

- 5.1 Correct oil level, gearboxes. Air line lubricator.
- 5.2 Mixing pan clear of loose nuts and bolts to prevent damage to fingers and blades.
- 5.3 Check correct rotation – mixing star – anti clockwise; mixing pan – anti clockwise. All when viewed from the top.
- 5.4 Discharge door and blade correct operation.
- 5.5 Blade operating clearances adjust in line with maintenance instructions.
- 5.6 Never exceed manufacturer’s maximum capacity as detailed in specification.

## **SHUTDOWN**

- 6.1 Prior to any work being carried out mixer to be isolated and physically locked off. Recommended equipment double key exchange system.
- 6.2 Follow procedure detailed in company and users’ Health and Safety Policy at all times.
- 6.2 Ensure all storage bins containing materials to be mixed are isolated.
- 6.3 Shut off water supply and drain off water tank or flowmeter

## **MAINTENANCE**

- 7.1 Ensure that all maintenance is carried out in accordance with the Parts and Operating manuals and any proprietary manufacturer's specific instruction.
- 7.2 Isolate electrical and other services to the mixer as section 6 above.
- 7.3 Service at recommended intervals.
- 7.4 Use Croker manufactured replacement parts supplied by **WINGET LIMITED**.

## **GENERAL**

- 8.1 Under no circumstances should the Maximum Batch Loads be exceeded by either weight or volume as stated in Technical Specification.
- 8.2 Mixer star blades to be checked daily for damage.
- 8.3 Pan rim and base wearing plates must be replaced before excessive wear causes distortion.
- 8.4 Ensure mixing pan is rotating concentrically and pan base is rotating in horizontal plane.
- 8.5 Mixer must not be stopped and started when there is mix in the pan.
- 8.6 Refer to Contract Drawing for scope of supply. Site instruction notes outlining weights etc.
- 8.7 Refer to Method Statement when installation and commissioning is responsibility of Winget Limited.

## **Nett Weights Max (kgs)**


9.1	RP50XD	788	RP1250XD	4840
	RP100XD	814	RP1500XD	4980
	RP200XD	1400	RP3000XD	7112
	RP400XD	2000	FP1000	4040
	RP550XD	2150	FP1500	4065
	RP850XD	2600	FP2000	4100

- 9.2 Refer to technical specification for nett weights of ancillary equipment.
- 9.3 Refer to contract drawing for nett weights of ancillary equipment.


## **Miscellaneous**

10.1 Noise measured in accordance with Directive 79/113 EEC 85db(a)LPA.



# RP850XD GENERAL ARRANGEMENT BASIC MACHINE



**NOTE: MIXER DRIVES  
MIXER STAR 18.5KW  
MIXER PAN 3KW**




# RP850XD GENERAL ARRANGEMENT WITH LOADER



**NOTES**  
 MIXING STAR MOTOR 18.5KW  
 PAN MOTOR 3.0KW  
 LOADER MOTOR 7.5KW


# GENERAL ARRANGEMENT OF RP850XD FITTED WITH BOTTOM DISCHARGE LOADER



OUTLINE ARRANGEMENT  
OF BOTTOM DISCHARGE  
LOADER FITTED TO  
CUMFLOW RP850XD  
MIXER

# RP850XD ARRANGEMENT OF BOTTOM DISCHARGE LOADING HOPPER

- 1 CR089045 L/HOPPER ASSEMBLY**
- 2 CR089046 L/FRAME ASSEMBLY**
- 3 CR089047 L/DRIVE ASSEMBLY**







**OPERATING**  
**AND**  
**MAINTENANCE MANUAL**

**SECTION 2**

**INSTALLATION AND OPERATING  
INSTRUCTIONS**

## **PRE-INSTALLATION**

On arrival of the equipment it is advisable to check that all packages listed on the consignment note have been received.

The equipment must be offloaded using certified lifting gear of suitable capacity, by a competent person.

When unloading the mixer, care must be taken to ensure the discharge chute remains clear of obstructions as the chute and door hang below the chassis.

An outline drawing and bolt hold plan is normally sent prior to the despatch of the machine and will enable preparations to be made for the installation. With the `picture` of what the machine will look like when it is assembled, the ancillary equipment dismantled for transport can easily be identified.

## INSTALLATION

Please refer to contract arrangement and site instructions as applicable.

It is recommended that a concrete foundation (to take foundation bolts – not supplied) should be provided for each leg of the support structure and runway when fitted. When the machine is supplied without a support structure it should be mounted on supports of sufficient strength and rigidity to prevent undue vibration when the machine is working. When making provision for a loading hopper pit it is strongly recommended that the pit is concreted out so that it can easily be kept clean and free from any build up which could prevent the bottom limit switch from operating correctly.

Before completing the installation, check that the main mixer frame is level with a spirit level. Packings should be inserted as required under the structure legs or main frame. The packings under the mixing pan roller brackets are set during manufacturing and must not be disturbed under any circumstances.

Check that the pan is seated and that the pan rack and drive gear are in mesh.. Also check that all the blade clearances are in line with the maintenance instructions.

On connecting to the power supply, the wiring diagram must be referred to. A check that the wiring is correct is rotation of the following:-

- The mixing pan and mixing star rotate anti-clockwise when looking from the top.
- The loader winch rotates anti-clockwise looking from the rope drum end and when the raise button is pressed.
- The whirler unit rotates clockwise when looking from the top.

It is advisable to mount the starters away from the machine on supports free from vibration. Ensure that the starters are fitted with suitable overloads – see technical specification – power units. **Note:- it is recommended that the mains electrical supply is taken via an earth leakage circuit breaker.**

A simple Water Flow Meter is available as an option to the water tank, this has a range of 0-100 litres and features an adjustable flow indicator with a reset facility allowing very accurate measurement of water flow irrespective of the pressure. The Flow Meter is normally fitted with a manual ‘on/off’ valve and is protected by a washable in line strainer.

A supply of compressed air at 5.5 bars is required. The inlet for the connection from the air line is tapped ½” B.S.P. A drop in pressure will cause incorrect operation of the pneumatic system.

## **OPERATING THE MACHINE**

Before starting production the following points should be checked:-

- (1) That there is oil in (a) the Star Drive Gearbox  
(b) the Pan Drive Gearbox  
(c) the Loader Winch Gearbox (when fitted)  
(d) the Air Line lubricator
- (2) The Mixing pan should be clear of loose nuts, bolts, spanners etc., as these will damage the fingers and blades.
- (3) Check that the Discharge Door and Discharge Blade are operating correctly.
- (4) Check that the blade clearances are correct and if necessary adjust, in line with the maintenance instructions.
- (5) Check that the limit switches on the loader stop the Loading Hopper in the required positions at the top and bottom of the runway and that the magnetic brake is applied.
- (6) Check that the Water tank is set to the required amount and is filling up to this level. (See later page for further information on Water Tank operation).
- (7) If a Flow Meter is fitted check that the pointer is reset to zero and the strainer is clean and free from debris.
- (8) When Weigh Gear is fitted check that the setting arrangements and any lubrication requirements have been carried out. .

### **IMPORTANT:**

The CUMFLOW is a high performance Mixer.

The following precautions are necessary to obtain the best results and to avoid damage to the Mixing Star and Drive.

### **AGGREGATES:**

Strict control of graded aggregates must be maintained. Maximum Size 25mm.

Oversize lumps of aggregate or rogue material must be prevented from entering the Pan.

### **MIXING STAR BLADES:**

They are of a special shape and material to prolong wear life. They should not be modified in any way and only replaced by genuine 'WINGET CROKER' spares.

Daily check is advised to ensure that the Blades/Wearing Pieces are securely bolted and undamaged.

### **PAN RIM & BASE WEARING PLATES:**

They must be replaced before excessive wear causes distortion.

### **MAXIMUM BATCH LOADS:**

**Under no circumstances should** the Maximum Batch Loads quoted be exceeded nor should the Mixer be stopped and re-started when there is a mix in the Pan.

After each mix the contents of the pan must be completely discharged before attempting to close the discharge door. At the end of each period of operation the mixing pan, mixing blades, discharge blade and fingers, discharge chute, discharge door and seating must be washed down to prevent concrete setting on them and so impairing the efficiency of the machine.

### **WARNING:**

**THE MAUFACTURER ACCEPTS NO RESPONSIBILITY FOR ANY DAMAGE OR FAILURE RESULTING FROM OPERATIONAL MIS-USE OR MALPRACTICE.**

## **OPERATING INSTRUCTIONS FOR WEIGH GEAR MECHANISM**

### **HYDROSTATIC LOADCELL & GAUGE**

The Hydrostatic Load Cell is connected by a flexible capillary tube (approx 9.7 metres long) to a 300mm (12") diameter weigh gauge.

The whole system is assembled and filled with fluid under vacuum and under no circumstances should any of the components be disconnected, in the event of component damage the complete assembly should be returned to Winget Limited for repair.

The system is factory calibrated and any variation between the calculated tare and the actual tare recorded can be corrected by means of the tare adjustment knob on the side of the gauge.

With no load acting on the loadcell the pointer will be below zero, this is to accommodate the weight of the hopper. When the hopper is placed on to the loadcell the pointer will register zero. Final zero adjustment can be made via the zero adjustment knob on the side of the gauge housing.

## **ELECTRONIC LOADCELL & GAUGE**

The electronic Loadcell & Gauge consists of an electrically operated loadcell mounted on the weigher frame and connected to a remote mounted digital readout control box. The connecting lead should be protected from damage and the readout box mounted such that it is not affected by vibrations etc. The mounting instructions detailed within Section 9 of this manual should be followed to avoid excess vibrations damaging the control box. Section 9 also contains detailed advice on setting up, obtaining zero and operation of the loadcell and readout box and should be referred to before the equipment is operated.

### **NOTE THE FOLLOWING WIRING CONNECTIONS**

- + Excite RED
- Excite BLUE
  
- + Signal GREEN
- Signal YELLOW

## **OPERATING INSTRUCTIONS FOR 0-100 LITRE WATER FLOWMETER**

The simple manually operated 0-100 litre Water Flow Meter is available as an option to the water tank and is normally mounted on the side of the mixer feeding directly into the pan. The meter is normally fitted with 1" hose tail connectors but different sizes of water inlet connections to suit various hose diameters are also available. The meter is normally provided with a simple 'on/off' valve and inline filter/strainer mounted next to but down stream of the flowmeter.

### **OPERATION**

On a daily basis before use the strainer should be removed and checked for debris and obstructions, cleaned and refitted. Ensure the on/off valve is in the 'off' position and turn on the main water supply. Set the adjustable pointer on the dial face via the central knob to the required amount of water. Check the

indicator reads zero, if not operate the reset lever on the side of the meter which will reset the indicator. Turn the on/off valve slowly to the 'on' position watching the movement of the indicator around the dial, when the indicator reaches the pointer sharply turn valve to the 'off' position. The indicator will register the amount of water delivered. Operate the reset lever to bring the indicator back to zero and repeat the operation for each batch of material mixed.

When shutting down the mixer either at night or at the end of each shift it is recommended that the main water supply to the flow meter and 'on/off' valve is shut off.

If it is expected that the overnight temperatures will drop to or close to freezing it is recommended that the Flow Meter, Valve, Filter and Pipework are drained to prevent damage.



# **OPERATING THE MIXER**

## **SAFETY NOTES**

Never operate the mixer unless you have read and fully understand the contents of the Operators Manual

Never operate the mixer whilst wearing loose fitting clothing

Never reach inside the Pan whilst it is rotating

Never operate any equipment unless you have received adequate training

Cement, certain other minerals and organic compounds can cause skin irritation leading to Dermatitis. Always use Personal Protective Equipment i.e. gloves etc to protect the skin from direct contact. If in any doubt about the materials being used consult your employers COSHH manual

Wear Eye protection to protect your eyes from dust and liquid splashes

Do not attempt to remove the pan single handedly, obtain assistance, use the Pan Trolley (if provided) or use suitable lifting equipment

Do not operate the mixer with any of the guards removed, safety devices or interlocks disconnected. They are there to offer you some protection, ensure they are correctly maintained

Carry out the daily maintenance before operating the mixer and report defects to your supervisors

Oils, Greases and Lubricants are skin irritants and prolonged direct skin contact can cause skin cancer. PPE or barrier creams should be used when carrying out maintenance work, wash your hands on completion

Always dispose of waste oils and lubricants in a proper manner, it is illegal to pour it down drains or bury it. Contact your local authority for a list of authorised disposal sites

Always disconnect the power supply at the mains before carrying out any maintenance work or cleaning the equipment down. Do not turn on the power until everything has dried out

Do not allow waste from the wash down process to enter the public drainage system unless it has been properly filtered.

Decals and Instruction Plates are attached to the equipment to warn against hazards and assist in the safe operation of the equipment, if damaged or defaced they should always be replaced.

It is likely that clutch and/or brake linings may contain asbestos and suitable precautions should be taken to avoid breathing in the dust, protective clothing should be worn. Hands should be washed immediately after handling components and old discarded parts or linings should be disposed of in a responsible manner in line with local or national regulations covering the disposal of asbestos waste.

**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 3**

**TECHNICAL SPECIFICATION  
AND MAINTENANCE**

## TECHNICAL SPECIFICATION OF CUMFLOW RP850XD

<b><u>CAPACITIES:</u></b>	Maximum Batch Capacity	by Weight	1300 kgs
		by Volume	850 litres
	Nominal Output (based on 2200kg/m <sup>3</sup> )		600 litres
<b><u>AGGREGATES:</u></b>	Maximum Aggregate Size		25 mm
<b><u>MIXER FRAME:</u></b>	Strongly constructed from welded Steel Channel		
<b><u>MIXING PAN:</u></b>	Steel Base Pan mounted on three wide track rollers with central discharge door. Pan Rim, Base and Discharge Door fitted with renewable Wearing Plates.		
<b><u>MIXING STAR:</u></b>	Twin Arm Mounting, Four Spring loaded Star Blades, Two at Pan floor level and Two for high level mixing.		
<b><u>FIXED BLADE:</u></b>	Spring loaded pan side scraper assembly. Reversible when worn		
<b><u>DISCHARGE BLADE:</u></b>	Pneumatically operated in conjunction with the Discharge Door.		
<b><u>WHIRLER:</u></b>	Intermittent blades mounted on vertical shaft.		
<b><u>POWER UNITS:</u></b>	Mixing Star)		18.5 kw
	Mixing Pan)		3.0 kw
	Loader Motor (where fitted)		7.5kw
	Bottom Discharge Loader (where fitted)		11.0kw
	Whirler Motor (where fitted)		15 kw
<b><u>DRIVES</u></b>	Mixing Pan	Gear unit with pinion and cast rack	
	Mixing Star	Gear unit directly mounted	
	Whirler	Vee Rope Drive	
<b><u>SPEEDS</u></b>	Speed of Pan		12 rpm
	Speed of Mixing Star		57 rpm
	Speed of Loading Hopper		21 metres/min
	Speed of Whirler		720 rpm
<b><u>FREE AIR CONSUMPTION (PER BATCH 80 PSI)</u></b>			63.7 litres
<b><u>WEIGHTS (UNLADEN)</u></b>	Without Loader		2600 kg
	With Loader (approx)		3725 kg
<b><u>ELECTRICS</u></b>	Motor Voltage		415V 3ph 50hz
			Option 60 hz
	Control Voltage		110V

## **MACHINE SAFETY DIRECTIVE**

All Gears are suitably guarded.

# MAINTENANCE

## IMPORTANT


**ALWAYS ENSURE APPARATUS IS ISOLATED FROM MAINS SUPPLY BEFORE COMMENCING MAINTENANCE.**

## SHUTDOWN PROCEDURE

Prior to any work being carried out the apparatus is to be isolated and physically locked off.

We recommend a double key exchange system.

Safe access to equipment with one access door and one control point.



Follow the procedures detailed in your Health and Safety Policy at all times.

Ensure all storage bins containing materials to be mixed are isolated.

Shut down the water supply and drain off any water tanks or flowmeter fitted

## **MAINTENANCE OF MIXER**

### **IMPORTANT NOTE:**

Ensure that all maintenance is carried out in accordance with the Parts and Operating Manual and Proprietary Manufacturer's specific instruction.

### **PROCEDURE**

- 1 ISOLATE ELECTRICAL, PNEUMATIC AND OTHER SERVICES TO THE MIXER (see separate section).
- 2 Service at recommended intervals.
- 3 Use Croker manufactured replacement parts available from WINGET LIMITED.
- 4 Ensure all safety guards and interlocks are reinstated prior to operating the mixer.
- 5 Main items of wear (see Section 4).
  - A) Star Blades
  - B) Fixed Blade
  - C) Discharge Blade
  - D) Whirler Blades

Access to mixing pan internals is via the safety interlocks. Each of the above are bolted components and are replaced by simple method and usually achieved in situ without dismantling other components.

- E) Pan base and rim wearing plates are also bolted construction and can be replaced in situ. However, pan covers will need to be dismantled to provide the necessary access.
- F) Other items prone to less wear are star blade fingers, lower whirler shaft assembly and mixing star. Each can be replaced again in situ but pan covers would require dismantling to provide necessary access.
- G) Pan rollers can be adjusted to accommodate wear during operation. These can be replaced when required in situ using jacking method to support pan and provide the necessary access.

## MAINTENANCE AND LUBRICATION

**DAILY:** Using Total Multis EP2 Grease 2 (or equivalent) grease the following points:-

Pan Roller Spindles	3 Points
Discharge Blade Lifting Gear Brackets	2 Points
Air Cylinder Lever Pivot Holder	1 Point
Mixing Blade Finger Bearings	2 Points
Fixed Blade Finger Bearing	1 Point
Loading Hopper Rollers	2 Points
Pan Drive Plummer Bearings	2 Points
Loader Rollers (Where fitted)	4 Points
Whirler (Where Fitted)	2 Points

Inspect and top-up if necessary:-

Air Line Lubricator

Use Total Azolla 27 (or equivalent)  
or suitable Pneumatic Tool Oil.

**WEEKLY:** Inspect and top up if necessary:-

(1) **Star Drive Gearbox (Capacities Approximate)**

**RENOLD UNITS**

Cap 23.8 litres. Use Total Carter EP320  
or Shell Omala 320 or equivalent.

**FLENDER UNITS**

Cap 17.5 litres. Use Total Carter EP220  
or Shell Omala 220 or equivalent.

**SEVER UNITS**

Cap 20.0 litres. Use Total Carter EP220  
or Shell Omala 220 or equivalent.

(2) **Pan Drive Gear Box Capacities Approximate)**

**RENOLD UNITS**

Cap 5.03 litres. Renold Pan Drives must  
be run on a synthetic not a mineral oil.  
Use Total Carter EPHT320 or Total  
Carter SY320 or Mobil Synthetic  
SHC632 or equivalent synthetic oils. The  
different synthetic oils will not mix with  
each other so the Gearbox must **always**  
be drained and flushed prior to topping  
up or refilling with a different make of oil



## **FLENDER UNITS**

Cap 5.03 litres. Flender Pan Drives must be run on a synthetic not a mineral oil. Use Total Carter EPHT460 or Total Carter SY460 or Tribol 800 ISO460 or B.P. Eersin SG-XP460 or equivalent synthetic oils. The different synthetic oils will not mix with each other so the Gearbox **must** be drained and flushed prior to topping up or refilling with a different make of oil..

## **SEVER UNITS**

Cap 5.1 litres. Sever Pan Drives must be run on a synthetic not a mineral oil. Use Total Carter EPHT460 or Total Carter SY460 or Tribol 800 ISO460 or B.P. Eersin SG-XP460 or Castrol Alphasyn PG680 or equivalent synthetic oils. The different synthetic oils will not mix with each other so the Gearbox **must** be drained and flushed prior to topping up or refilling with a different make of oil..

### **(3) Loader Winch Gearbox (Flender)**

Cap 5.0 litres. Use Total Carter EP220 or Shell Omala 220 or equivalent.

## **Inspect and Adjust**

- (1) Pan Gear and Pinion – Apply Open Gear Lubricant (or equivalent) as required.
- (2) Adjust Star Blades, Fixed Blades and Discharge Blade to the following settings, also make sure that Blade fingers are free in their bearings and that the springs are clear of obstructions.

Mixing Blade: (3 mm) clear of pan base. Adjust by moving the blade down its finger.

Discharge Blade: Just touching pan base when finger bridge is resting on stop sleeves. Adjust by moving bridge up or down fingers.

Fixed Blade: (3 mm) clear of pan base and just touching pan rim. Adjust by moving hinge brackets along its slots and blade up or down its fingers. Re-set spring to 100 mm overall length after setting blade.

- (3) After the first week's running the Whirler Vee Belt Drive will need adjustment to take up initial wear and stretch. At the correct tension it should be just possible to twist each belt through 90° when gripped between finger and thumb midway between pulleys.
- (4) Loading Hopper Wire Rope – clean off grit etc. and inspect for broken strands. Clean and apply a suitable wire rope dressing.

## **500 HOUR MAINTENANCE FOR PAN AND STAR DRIVE GEAR UNITS**

After 500 running tours, the Gearboxes should be drained and thoroughly flushed with a light flushing oil and refilled with new oil of the correct grade listed below. It is advisable to drain, flush and refill with new oil after every 12 months, or more often if operating conditions are severe.

To fill the Gearboxes, remove the oil level plug and the filler breather plug and pour in oil until it flows from the level hole. Replace the plugs making sure that the vent holes in the filler breather plug are clear. Refer to the following notes.

### **RENOLD UNITS**

Capacity of Star Gearbox: (approximate) 23.8 litres  
 Use Total Carter EP320 or Shell Omala 320 or equivalent

Capacity of Pan Gearbox: (approximate) 5.03 litres

The Renold Pan Drives must be run on a synthetic oil not a mineral. Use Total Carter EPHT320 or Total Carter SY320 or Mobil SHC632 (Synthetic Oils). The different synthetic oils will not mix with each other so the gearbox must be drained and flushed prior to topping up or refilling with a different make of oil.

### **FLENDER UNITS**

Capacity of Star Gearbox (approximate) 17.5 Litres  
 Use Total Carter EP220 or Shell Omala 220 or equivalent.

Capacity of Pan Gearbox (approximate) 5.03 Litres

The Flender Pan Drives must be run on a synthetic oil not a mineral. Use Total Carter EPHT460 or Total Carter SY460 or Tribol 800-ISO460 or B.P. Enersin SG-XP460 (Synthetic Oils). The different synthetic oils will not mix with each other so the gearbox must be drained and flushed prior to topping up or refilling with a different make of oil.

## **SEVER UNITS**

Capacity of Star Gearbox (approximate) 20.0 Litres

Use Total Carter EP220 or Shell Omala 220 or equivalent.

Capacity of Pan Gearbox (approximate) 5.01 Litres

The Sever Pan Drives must be run on a synthetic oil not a mineral. Use Total Carter EPHT460 or Total Carter SY460 or Tribol 800 ISO460 or B.P. Enersin SG-XP460 or Castrol Alphasyn PG680 or equivalent synthetic oil. The different synthetic oils will not mix with each other so the gearbox must be drained and flushed prior to topping up or refilling with a different make of oil.

### **MONTHLY:      Inspect:**

- (1) All blades for wear – replace when worn.
- (2) Pan rim, base and door wear plates – replace when worn
- (3) Pan Roller Bearings – replace if necessary
- (4) Pan Door Bearing – replace if necessary
- (5) Pneumatic system for leaks – repair or replace damaged parts.
- (6) Pneumatic Cylinders. Make sure that the door cylinder piston rod is at the end of its travel when the discharge door is just home in its seating.
- (7) Check the S.H. bushing securing the Mixing Star and Pan Drive to their respective gearbox shafts are tight. Torque setting 34 nm.

### **CAUTION:      BEFORE WORKING UNDER LOADING HOPPER, REST HOPPER ON SAFETY BOLTS. DO NOT FORGET TO REMOVE THESE BOLTS BEFORE RE-STARTING THE MACHINE**

(Item 45 on arrangement of Loader Section)

- (8) Loader Magnetic Brake – adjust if necessary, to the following instructions (these instructions apply only if a separate brake unit is fitted, refer to the manufacturer if a combined motor and brake unit is fitted):-

#### **Mounting:**

Set the brake so that the horizontal centre-line of the shoe corresponds with the centre-line of the brake wheel shaft and the shoe pivots are equally spaced from the vertical centre-line.

### Installing:

Slacken back equalising screw (Item 14) Slack nut (Item 5) and adjust screw (Item 3) to give required braking torque.

### WARNING:

The end of the adjusting screw (Item 3) must always be visible in the hole at the end of the adjusting nut (Item 6).

Set nuts (Item 5) so that contact is made with the load spring block in the shoe lever when solenoid plunger has moved through half its stroke. Once properly set, this setting should not be altered. With solenoid plunger right down, set equalising screw (Item 14) to give equal friction lining clearances.

Tighten locknuts (Item 5 & Item 14) and be sure that the load spring bracket is in place.

Check adjustments frequently and lubricate brake shoe pivots. To adjust for wear, screw in adjusting screw (Item 3) until the adjusting nuts are clear and only touch lever (Item 1) when plunger is depressed through half its stroke.

When new linings are fitted, repeat all adjustments.

Orders and enquiries should always state full description of parts required together with the make and model of brake and motor. The serial number on the brake should always be quoted and when ordering replacement brake shoes give the dimensions and number of rivet holes.

Check that the limit switch on the loader stops the hopper in the required position at the top of the runway.

When operated the limit switch should stop the motor and apply the magnetic brake unit.

If a Batch Weigher is not to be used in conjunction with the Loader, then the skip track must be extended and a lower limit switch and hopper stops incorporated.

The loading hopper must operate the lower limit switch before the hopper stops are reached and allowance made for the rope to slacken once the hopper is in the loading position.

## **ANNUALLY:**


### **Loader Winch Gear Box (Flender):**

Drain and clean out the gear case and refill with Total Carter EP220 or Shell Omala 220 or equivalent. When running conditions are severe this procedure should be adopted more frequently. Approximate Capacity 5 litres.

## **NOTE**

Electrical cables particularly those with copper conductors suffer from a condition known as 'relaxation' which may cause wiring to work loose over a period of time, it is recommended that the tightness of wiring connections and terminals are checked following the first month in service.

# LUBRICATION LAYOUT




## **LUBRICATION LAYOUT**

<b><u>ITEM</u></b>	<b><u>PART NO.</u></b>	<b><u>DESCRIPTION</u></b>	
1	CR540221	Lubrication Panel	1
2	131S01	Grease Nipple	7
3	CR510012	Straight Connector	7
4	CR289006	Straight Connector	A/R
5	CR289004	Tube Nut	A/R
6	CR269007	Tube Olive	A/R
7	CR510415	Bundy Tube	A/R

The bundy tube part number CR510415 is supplied in 3.05mt lengths, order lengths as required.

# LUBRICATION CHART






**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 4**

**MIXER SPARE PARTS**

RP850XD GENERAL ARRANGEMENT OF PARTS & TOP AND BOTTOM STRUCTURES




## RP850XD GENERAL ARRANGEMENT + TOP + BOTTOM STRUCTURE

1	*	Arrangement of Mixing Star	1
2	*	Discharge Blade Assembly	1
3	*	Pan Door Assembly	1
4	*	Fixed Blade Assembly	1
5	*	Pan Roller Assembly	3
6	*	Door Control Assembly	1
7	CR26100001	Top Structure Assembly	1
8	CR531000312	Top Structure Support	1
8A	CR531000322	Top Structure Support	1
9	CR531000321	Top Structure Support	1
10	CR531000311	Top Structure Support	1
11	CR261000000	Chassis	1
12	CR26100008	Pan Base, Mild Steel	1
12A	CR26100008SS	Pan Base, Stainless Steel	1
13	CR21100009	Pan Rack	1
14	CR54100010	Pan Rim, Mild Steel	1
14A	CR54100010SS	Pan Rim, Stainless Steel	1
15	CR53100011	Pan Base Wear Plate, Mild Steel	4
15A	CR53100011SS	Pan Base Wear Plate, Stainless Steel	4
15B	CR53100011H	Pan Base Wear Plate, Wear Resistant Steel	4
16	CR54100012	Pan Rim Wear Plate, Mild Steel	3
16A	CR54100012SS	Pan Rim Wear Plates, Stainless Steel	3
16B	CR54100012H	Pan Rim Wear Plates, Wear Resistant Steel	3
17	*	Pan Drive Assembly	1
18	8S05D	Bolt M12	2
18A	61S05	Nut Binx M12	2
18B	267S07	Washer flat M12	4
19	11S05D	Screw set M12	2
19A	61S05	Nut Binx M12	2
19B	267S07	Washer Flat M12	2
21	CR54100052	Pan Guard Bottom Ring (Welded)	1
22	CR26100062	Pan Rim Sealing Track	1
23	CR53100077	Door Seating, Mild Steel	1
23A	CR53100077SS	Door Seating, Stainless Steel	1
*31	*CR299078A	*Mixing Star Gearbox Flender	1
*31	*CR299078B	*Mixing Storage Box Renold	1
*31	*CR299078C	*Mixing Star Gearbox Sever UK Spec	1
*31	*CR299078D	*Mixing Star Gearbox Sever US/CAN Spec	1
31A	8S06F	Bolt M16	8
31B	61S06	Nut Binx M16	8
31C	267S09	Washer Flat M16	8
*32	*CR299079A	Pan Drive Gearbox Flender	1
*32	*CR299079B	Pan Drive Gearbox Renold	1
*32	*CR299079C	Pan Drive Gearbox Sever UK Spec	1
*32	*CR299079D	Pan Drive Gearbox Sever US/CAN Spec	1
34	8S06D	Bolt M16 Support-Structure & Chass	32
35	61S06	Nut Binx M16 Support-Structure & Chassis	32
42	267S09	Washer Flat M16 Structure & Chassis	32

\* Quote make and model when ordering parts for these assemblies

\* Refer to relevant pages for breakdowns of these assemblies


RP850XD PAN ROLLER ASSEMBLY



# RP850XD PAN ROLLER ASSEMBLY

1	CR21100071	Pan Roller	3
2	CR26100072	Pan Roller Spindle	3
3	CR53100073	Dust Washer	3
4	CR54100074	Dust Cap	3
5	CR150062	Bearing Ball	3
6	CR150126	Bearing Ball	3
7	CR531317	Packing (not illustrated) 1.5 mm Thick	A/R
8	CR531316	Packing (not illustrated) 3mm Thick	A/R
9	CR531315	Packing (not illustrated) 6mm Thick	A/R
10	CR531314	Packing (not illustrated) 10mm Thick	A/R
11	8S06K	Bolt M16 x 70	3
12	8S06E	Bolt M16 x 45	6
13	105S07	Washer Tapered M16	9
14	267S09	Washer Flat M16	9
15	61S06	Nut Binx	9


# RP850XD DOOR CONTROL ASSEMBLY



# RP850XD DOOR CONTROL ASSEMBLY

1	CR110305	Air Cylinder	1
1A	CR110326	Seal Kit Air Cylinder	1
1B	CR119265	1/2" BSP Male x 12mm Female Push In Elbow	
		Discharge Door Cylinder Both Ends	2
1C	CR119261	Alternative 1/2" BSP Male x 12mm Female Push In Straight Adaptor Dis Door Cylinder Both Ends	2
2	CR26100043	Lever Pivot Holder	1
3	CR52100044	Pin Pivoit	1
3A	44S04E	Pin Split	2
3B	10S65	Washer Flat	4
4	CR53100063	Door Arm Lever	1
4A	CR329002	Key Parallel 9 x 14 x 80	1
4B	57S05D2	Screw Grub	1
5	CR54100078	Trunnion Plate	1
5A	7S05	Nut M12	4
5B	17S06	Washer Spring M12	4
5C	267S07	Washer Flat M12	4
6	CR53100075	Trunnion Plate	1
7	CR180014	Torsion Bush	1
8	CR159013	Pillow Block Bearing	2
8A	8S05D	Bolt M12	4
8B	61S05	Nut Binx M12	4
8C	267S07	Washer Flat M12	4
9	CR530039	Bearing Stop	2
9A	11S06G	Screw Set M12	2
9B	61S06	Nut Binx M12	2
9C	267S09	Washer Flat	2
10		Door Assembly	1
11	CR54100047A	Discharge Chute	1
11A	CR54100047B	Discharge Chute	1
11B	8S04D	Bolt M10	6
11C	7S04	Nut M10	6
11D	17S05	Washer Spring M10	6
12	CR54100070	Door Cylinder Guard	1
12A	11S04C	Screw Set M10	2
12B	61S04	Nut Binx M10	2
12C	267S06	Washer Flat M10	2
14	CR242113	Bolt Special	1
14A	7S08	Nut M24	1
14B	17S11	Washer Spring M24	1
14C	267S12	Washer Flat M24	1
17	7S08	Nut M24	2
28	CR53100064	Door Shaft Bracket	1
28A	8S06E	Screw Set M16	2
28B	61S06	Nut Binx M16	2
28C	267S09	Washer Flat M16	4
29	CR53100065	Door Shaft Bracket	1
29A	8S06E	Screw Set M16	2
29B	61S06	Nut Binx M16	2
29C	267S09	Washer Flat M16	4
31	CR26100045	Door Arm	

# RP850XD PAN DRIVE ASSEMBLY






# RP850XD PAN DRIVE ASSEMBLY

1	CR26100301	Pan Drive Chassis	1
2	CR52100042	Pan Drive Shaft	1
3	CR46100034	Bevel Pinion	1
6	CR159012	Bearing Plummer Block	2
7	CR530039	Bearing Stop	4
8	CR189003	Bushing, Taper Lock	1
9	CR239031	Flexible Coupling Assembly, Sever Gearbox	1
9A	CR239036	Bush, Taperlock 45mm Dia , Gearbox Side	1
9B	CR239037	Bush, Taperlock 50mm Dia , Bevel Pinion Side	1
9C	185S05K1	Screw Grub 5/8" BSW X 1.25"	4
9	CR239011	Flexible Coupling Assembly, Flender Gearbox	1
9A	CR239040	Bush Taperlock 48mm Dia, Gearbox Side	1
9B	CR239037	Bush, Taperlock 50mm Dia , Bevel Pinion Side	1
9C	185S05K1	Screw Grub 5/8" BSW X 1.25"	4
*10	*CR299079A	*Pan Drive Gearbox Flender 3.0kw	1
	CR229211	Motor for Pan Drive Gearbox CR299079A	1
*10A	*CR299079B	*Pan Drive Gearbox Renold 3.0kw	1
*10B	*CR299079C	*Pan Drive Gearbox Sever UK Spec 3.0kw	1
*10C	*CR299079D	*Pan Drive Gearbox Sever US/CAN Spec 3.0kw	1
*10D	*CR299160	*Pan Drive Gearbox 5.0kw (Special Applications)	1
11	CR329077	Key Parallel	2
12	8S06K	Bolt M16 x 70	8
13	8S06H	Bolt M16 x 60	4
14	61S06	Nut Binx M16	12
15	267S09	Washer Flat M16	12
16	8S06K	Bolt M16 x 70	4
17	267S09	Washer Flat M16	8
18	17S08	Washer Spring M16	4
19	7S06	Nut M16	4
20	CR53100305	Packing (not illustrated)	A/R
21	CR53100306	Packing Single Hole Thick (not illustrated)	A/R

Items 16,17,18,19 Secure pan drive chassis to main chassis unit

\*Quote Make & Model of motor/gearbox when ordering spares for this item


# RP850XD PAN ASSEMBLY



# RP850XD PAN ASSEMBLY

1	CR54100010	Pan Rim, Mild Steel	1
1A	CR54100010SS	Pan Rim, Stainless Steel	1
2	CR21100009	Pan Rack	1
3	CR26100008	Pan Base, Mild Steel	1
3A	CR26100008SS	Pan Base, Stainless Steel	1
4	CR54100012	Pan Rim Wear Plates, Mild Steel	3
4A	CR54100012SS	Pan Rim Wear Plates, Stainless Steel	3
4B	CR54100012H	Pan Rim Wear Plates, Wear Resistant Steel	3
5	CR53100011	Pan Base Wear Plates, Mild Steel	4
5A	CR53100011SS	Pan Base Wear Plates, Stainless Steel	4
5B	CR53100011H	Pan Base Wear Plates, Wear Resistant Steel	4
6	CR53100077	Door Seat, Mild Steel	1
6A	CR53100077SS	Door Seat, Stainless Steel	1
7	52S03E	C'Sunk Bolts M8 x 25 (Pan Rim Wear Plates)	30
7A	61S03	Nut Binx M8	30
7B	267S05	Washer Flat M8	30
8	52S05J	C'Sunk Bolts M12 x 45 (Pan Rack-Pan Base)	16
8A	61S05	Nut Binx M12	16
8B	267S07	Washer Flat M12	16
9	52S03H	C'Sunk Bolts M8 x 40 (Door Seat-Pan Base)	8
9A	61S03	Nut Binx M8	8
9B	267S05	Washer Flat M8	8
10	8S04D	Hex Head Bolts M10 (Pan Rim to Track)	16
10A	61S04	Nut Binx M10	16
10B	267S06	Washer Flat M10	32
11	52S06H	C'Sunk Bolts M16 x 40 (Wear Plates-Pan Base)	16
11A	7S06	Nut M16	16
11B	17S08	Washer Spring M16	16
11C	267S09	Washer Flat M16	16


# RP850XD DISCHARGE DOOR ASSEMBLY



# RP850XD ASSEMBLY OF DISCHARGE DOOR

1	CR26100018	Door, Mild Steel	1
1A	CR26100018SS	Door, Stainless Steel	1
2	CR53100027	Door Wear Plate, Mild Steel	1
2A	CR53100027SS	Door Wear Plate, Stainless Steel	1
2B	CR53100027H	Door Wear Plate, Wear Resistant Steel	1
3	CR26100016	Door Pin	1
4	CR26100017	Bearing Housing	1
5	CR49100029	Door Pin Seal Washer	1
6	CR53100033	Support Angle	3
7	CR54100028	Safety Retainer	3
8	CR120003	Anti - Vibration Mounts	3
8A	17S05	Washer Spring M10	6
8B	7S04	Nut M10	6
9	CR63100030	Bearing Spacer	1
10	88S16D	Ball Bearing	2
11	CR560001	Felt Strip	2
12	8S04D	Bolt M10 x 40	6
12A	267S06	Washer Flat M10	6
12B	17S05	Washer Spring M10	6
12C	7S04	Nut M10	6
13	52S06M	Countersunk Screw M16 x 50	4
13A	267S09	Washer Flat M16	4
13B	17S08	Washer Spring M16	4
13C	7S06	Nut M16	4
14	52S04G	Countersunk Screw M10 x 35	2
14A	17S05	Washer Spring M10	2
14B	7S04	Nut M10	2
15	52S03G	Countersunk Screw M8 x 35	8
15A	17S04	Washer Spring M8	8
15B	7S03	Nut M8	8
16	61S07	Nut Binx M20	1
16A	267S10	Washer Flat M20	1
17	7S04	Nut M10	6
17A	17S05	Washer Spring M10	6
17B	267S06	Washer Flat M10	6


# RP850XD DISCHARGE BLADE ASSEMBLY



# RP850XD DISCHARGE BLADE ASSEMBLY

1	CR26100019	Finger Bridge	1
2	CR52100026	Discharge Blade Finger, Mild Steel	2
2A	CR52100026SS	Discharge Blade Finger, Stainless Steel	2
3	CR21100021	Finger Bracket	2
4	CR54100020	Discharge Blade, Mild Steel	1
4A	CR54100020SS	Discharge Blade, Stainless Steel	1
4B	CR54100020H	Discharge Blade, Wear Resistent Steel	1
5	CR531582	Piston Rod End	1
5A	CR489001	Pin Roll (Later Machines)	1
5B	57S04D2	Screw Grub M10 (Early Machines)	1
6	CR53100023	Tube Stop	2
7	CR53100025	Wiper Seal Housing, Mild Steel, Metric	4
7	CR53100460SS	Wiper Seal Housing, Stainless Steel, Metric	4
7A	CR579030	Seal Wiper, Metric	4
7B	11S02D	Screw Set M6	16
7C	17S03	Washer Spring M6	16
7D	267S04	Washer Flat M6	16
8	CR53100024	Air Cylinder Support (Obsolete from S/NO 6028)	
9	CR53100046	Bracket Support	2
10	CR110304	Air Cylinder	1
10A	CR110323	Seal Kit Air Cylinder Repair	1
10B	CR119264	Elbow Inlet/Outer	2
11	131S01	Nipple Grease Straight 1/8 BSP	2
11A	176S01	Cover Nipple Grease	2
12	7S03	Nut M8	4
12A	17S04	Washer Spring M8	4
12B	267S05	Washer Flat M8	4
13	7S08	Nut M24	4
14	267S12	Washer Flat M24	2
18	11S06G	Screw Set M16 x 45	4
18A	7S06	Nut M16	4
18B	17S08	Washer Spring M16	4
18C	267S09	Washer Flat M16	4
18D	150S07	Taper Washer M16	4
19	11S06G	Screw Set M16 x 45	4
19A	7S06	Nut M16	4
19B	17S08	Washer Spring M16	4
19C	267S09	Washer Flat M16	4
20	8S06G	Bolt M16 x 45 (Obsolete from S/no 6028)	2
20A	17S08	Washer Spring M16 (see above)	2
20B	267S09	Washer Flat (Obsolete from 6028)	2
20C	7S06	Nut M16 (Obsolete from S/no 6028)	2
21	52S06P	Screw C/Sunk M16 x 70	4
21A	7S06	Nut M16	4
21B	17S08	Washer Spring M16	4
21C	267S09	Washer Flat M16	4
24	8S06D	Bolt M6 x 40	4
24A	17S08	Washer Spring M16	4
24C	267S09	Washer Flat M16	4

RP850XD MIXING STAR ASSEMBLY






# RP850XD ARRANGEMENT OF MIXING STAR

1	CR26100003	Mixing Star, Mild Steel	1
1A	CR26100003SS	Mixing Star, Stainless Steel	1
2	CR26100004	Star Blade Finger, Mild Steel (Long)	2
2A	CR26100004SS	Star Blade Finger, Stainless Steel (Long)	2
3	CR26100005	Star Blade Finger, Mild Steel (Short)	2
3A	CR26100005SS	Star Blade Finger, Stainless Steel (Short)	2
4	CR210035	Star Blade (obsolete use item 4A below)	
4A	CR21100015	Star Blade, Cast, Standard	4
4B	CR210035P	Star Blade, Polyurethane, do not use on RP850/XD & above see item 4C & 4D below	
4C	CR219008P	Star Blade, Standard Duty Polyurethane	4
4D	CR219008HP	Star Blade, Heavy Duty Polyurethane	4
5	CR63100007	Spacer	2
6	CR26100006	Lever for Compression Spring, part of item 2 and 2A not supplied separately from either item	
7	CR330070	Spring Compression	2
8	CR189006	Bush Oilite	4
9	CR189005	Bush SHT Taper Lock 70mm Dia Shaft	1
9A	CR539189	Cap End	1
9B	11S02B	Screw Set M6 x 20	1
9C	17S03	Washer Spring M6	1
9D	11S07F	Screw Set M20 x 40	1
9E	17S09	Washer Spring M20	1
10	CR329068	Key Parallel Star Blade Finger	2
11	CR280008	Grease Nipple	2
12	11S05E	Hex Head Screw M12 x 35	4
12A	7S05	Nut M12	4
13	8S06K	Hex Head Bolt M16 x 70	8
13A	61S06	Nut Binx M16	8
13B	267S09	Washer Flat M16	8
14	11S07T	Hex Head Bolt M20 x 100	2
14A	7S07	Nut M20	2


# RP850XD FIXED BLADE ASSEMBLY



# RP850XD FIXED BLADE ASSEMBLY

1	CR530034	Fixed Blade, obsolete use item 1 below	
1	CR53100039	Fixed Blade, Mild Steel	1
1A	CR53100039SS	Fixed Blade, Stainless Steel	1
1B	CR53100039H	Fixed Blade, Wear Resistant Steel	1
2	CR53100040	Fixed Blade Angle, Mild Steel	1
2A	CR53100040SS	Fixed Blade Angle, Stainless Steel	1
3	CR26100035	Fixed Blade Finger, Mild Steel	1
3A	CR26100035SS	Fixed Blade Finger, Stainless Steel	1
4	CR26100038	Finger Pivot, Mild Steel	1
4A	CR26100038SS	Finger Pivot, Stainles Steel	1
5	CR53100037	Trunnion Plate	1
6	CR53100036	Trunnion	1
7	CR53100041	Trunnion Adjusting Rod	1
8	CR330066	Spring	1
9	CR49100059	Adjusting Rod Washer (Spring Ends)	2
10	44S06L	Split Pin	1
10A	CR49100801	Washer Machined	1
11	131S01	Grease Nipple 1/8" BSP	1
11A	176S01	Cover Nipple Grease	1
12	52S05H	Countersunk Screw M12 x 40	2
12A	7S05	Nut M12	2
12B	17S06	Washer Spring M12	2
12C	267S07	Washer Flat M12	2
13	8S05M	Bolt M12 x 80	2
13A	7S05	Nut M12	2
13B	17S06	Washer Spring M12	2
13C	267S07	Washer Flat M12	2
14	8S05M	Bolt M12 x 80	2
14A	61S05	Nut Binx M12	2
14B	267S07	Washer Flat M12	2
16	7S07	Nut M20	2
17	272127006	Washer Flat Special	1
18	8S06G	Hex Head Bolt M16 x 55	2
18A	61S06	Nut Binx M16	2
18B	267S09	Washer Flat M16	2
18C	CR530647	Washer Square	2

# RP850XD PAN GUARDS



GUARD ITEM 6 IS A STRUCTURAL SUPPORT FOR THE PAN DUST TRACK AND SHOULD NOT BE COMPLETELY REMOVED WHEN REMOVING THE PAN RIM GUARDS ITEMS 5. IF GUARD ITEM 6 OVERLAPS THE PAN RIM SUPPORT GUARDS THE SCREWS RETAINING ITEM 6 SHOULD BE SLACKENED ONLY BY THE AMOUNT REQUIRED TO ALLOW THE PAN RIM GUARDS ITEMS 5 TO BE SLID OUT FROM BEHIND IT.

# RP850XD LAYOUT OF GUARDS

1	CR54100049	Front Pan Guard Access	1
1A	11S03A	Screw Set M8	4
1B	17S04	Washer Spring M8	4
1C	267S05	Washer Flat M8	4
2	CR54100303	Side Guard-LH Plain	1
2A	11S03A	Screw Set M8	8
2B	17S04	Washer Spring M8	8
2C	267S05	Washer Flat M8	8
3	CR54100304	Side Guard-RH with Control Box	1
3A	11S03A	Screw Set M8	8
3B	17S04	Washer Spring M8	8
3C	267S05	Washer Flat M8	8
4	CR54100302	Top Guard	1
4A	11S03A	Screw Set M8	8
4B	17S04	Washer Spring M8	8
4C	267S05	Washer Flat M8	8
5	CR54100081	Pan Rim Guard LH & RH ( <b>SEE NOTE</b> )	2
5A	11S03A	Screw Set M8	12
5B	17S04	Washer Spring M8	12
5C	267S05	Washer Flat M8	12
6	CR54100082	Support Rear Pan Track & Guards ( <b>SEE NOTE</b> )	1
6A	11S03A	Screw Set M8	4
6B	17S04	Washer Spring M8	4
6C	267S05	Washer Flat M8	4
7	CR54100087	Splash Guard (Obsolete from 6029)	1
7A	11S03C	Screw Set M8	4
7B	17S04	Washer Spring M8	4
7C	267S05	Washer Flat M8	4
7D	7S03	Nut M8	4
8	CR54100088	Splash Guard (Obsolete from 6029)	1
8A	11S03C	Screw Set M8	4
8B	17S04	Washer Spring M8	4
8C	267S05	Washer Flat M8	4
8D	7S03	Nut M8	4
9	CR54100089	Splash Guard (Obsolete from 6029)	1
9A	11S03C	Screw Set M8	4
9B	17S04	Washer Spring M8	4
9C	267S05	Washer Flat M8	4
9D	7S03	Nut M8	4
10	CR54100051	Cover Plate Air Valve	1
10A	11S03A	Screw Set M8	4
10B	17S04	Washer Spring M8	4
10C	267S05	Washer Flat M8	4


Items 7,8 & 9 Splash Guards have been built into the Top Structure P/NO CR26100001 from S/NO 6029. They are still available as spares for machines prior to 6029.

**See important note regarding removal of Guard/Support item 6 before attempting to remove Pan Rim Guards items 5**

# RP850XD LAYOUT OF GUARDS

11	CR54100299	Pinion & Drive Guard	1
11A	11S03C	Screw Set M8	4
11B	17S04	Washer Spring M8	4
11C	267S05	Washer Flat M8	4
11D	7S03	Nut M8	4
12	CR54100796	Cover Plain, refer to contract specific items for details of Special Pan Covers	1
12A	11S03A	Screw Set M8	8
12B	17S04	Washer Spring M8	
12C	267S05	Washer Flat M8	8
13	CR539168	Guard Discharge Blade Fingers	1
13A	555287900	Spacer, Guard Support	3
13B	8S05U	Bolt M12	3
13C	7S05	Nut M12	3
13D	17S06	Washer Spring M12	3
13E	267S07	Washer Flat M12	3
14	CR54100797	Cover Top Sever Star Drive	1
14A	CR54100783	Cover Top Flender Star Drive	1
14B	CR54100782	Cover Top Infill	1
14C	11S03A	Screw Set M8	8
14D	17S04	Washer Spring M8	8
14E	267S05	Washer Flat M8	8
15	CR54100781	Cover Top LH	1
15A	11S03A	Screw Set M8	4
15B	17S04	Washer Spring M8	4
15C	267S05	Washer Flat M8	4
16	CR54100780	Cover Top RH	1
16A	11S03A	Screw Set M8	4
16B	17S04	Washer Spring M8	4
16C	267S05	Washer Flat M8	4
17	CR119190	Box Control	1
21	V2003587	Seal Rubber (order by metre)	A/R
22	V2003225	Seal Rubber (order by metre)	A/R

# RP850XD PAN SEALING STRIP



## RP850XD PAN SEALING STRIP

1	CR479004	Pan Sealing Rubber	4
2	CR539125	Retaining Plate	4
3	CR529035	Spacer	20
4	8S03C	Screw Set M8 x 35	20
5	61S03	Nut Binx M8	20
6	267S05	Washer Flat M8	20
7	CR54100777	Guard Wrap Round	3
8	V2003587	Seal Rubber	3MT
9	11S03A	Screw M8	12
10	17S04	Washer Spring M8	12
11	267S05	Washer Flat M8	12
12	CR26100062	Pan Dust Track	1

The following track retaining brackets are not illustrated

13	8S05D	Bolt M12 Track to top Structure Rear	2
13A	61S05	Nut Binx M12	2
13B	267S07	Washer Flat M12	4
14	11S05D	Screw Set M12 Track to rear Bracket	2
14A	61S05	Nut Binx M12	2
14B	267S07	Washer Flat M12	2
15	CR26100779	Bracket Track to Front Bracket	1
15A	11S03C	Screw Set M8	1
15B	17S04	Washer Set M8	1
15C	267S05	Washer Flat M8	8
16	CR26100778	Bracket, Track Bracket to Top Structure Front	1
16A	11S04B	Screw Set M10	1
16B	17S05	Washer Spring M10	1
16C	267S06	Washer Flat, M10	1



# RP850XD DECALS AND LOGOS

1 CROKER CUMFLOW RP850XD


<b>WINGET</b> WINGET LIMITED 125, 127 & 129, The Bridge Lane, Bilsborrow Lancashire, LA5 2JG, UK	
Model	
Serial No.	
Engine No.	
Capacity	Mass (kg)
SRO No.	Power (kW)
Year Of Manuf.	Eng. (rpm) Drum (rpm)

A CROKER GROUP COMPANY

2

**WINGET**

4




5



6




7




8

9



10



11

**SAFETY WARNING**


- 1 Before starting this machine the operator should be familiar with the operating instructions issued by the manufacturer
- 2 The manufacturer's rated capacity must never be exceeded
- 3 Before carrying out any maintenance servicing, or greasing, always ensure that the engine has been switched off. Never work on a machine while it is running.

WINGET RP850XD


12

**DANGER**  
DO NOT WALK, STAND OR LEAN  
UNDER RAISED HOPPER UNLESS  
IT IS SECURELY PROPPED

13

 THE BATCH LOADER MUST  
BE GUARDED TO PREVENT  
ACCESS WHEN MIXER IS  
IN OPERATION.

14

 THE TOP OF THE PAN  
MUST BE GUARDED TO  
PREVENT ACCESS WHEN  
MIXER IS IN OPERATION.

# RP850XD DECALS AND LOGOS

1	CR85100767	Decal RP850XD	3
2	V2003037	Plate Serial Number	1
3	101S05D	Rivet Pop	4
4	V2003039	Decal 'Winget' Medium	3
5	V2003665	Decal Sling Point	4
6	V2003598	Decal British Made	3
7	V2004307	Decal Electrical Hazard	5
8	V2004223	Decal 'CE' mark EC Machines Only	1
9	V2004229	Decal Operators Handbook	3
10	V2004744	Decal Eye Protection	3
11	504694600	Decal Safety	3
12	513331600	Decal Danger	8
13	CR85100771	Decal Batch Loader Guarding	2
14	CR85100772	Decal Pan Guarding	2

**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 5**



**OPTIONAL ANCILLARY EQUIPMENT  
SPARE PARTS**



# RP850XD WINCH ASSEMBLY

1	CR299114	Combined Motor Brake & Gear Unit (Flender)	1
2	CR269161	Motor Bedplate	1
3	CR21100101	Rope Drum Motor Side	1
4	CR21100102	Rope Drum	1
5	CR151096	Rope Drum Shaft Bearing	1
6	CR52100119	Rope Drum Shaft	1
7	CR630244	Locking Collar	1
7A	57S07F1	Screw Grub M12 X 16	3
8	CR329072	Key Parallel 18 X 11 X 140	1
9	CR329092	Key Parallel 18 X 11 X 100	2
10	CR569028	Loctite Fluid	1
11	8S07N	Hex Head Bolt M20 X 90	4
11A	61S07	Nut Binx M20	4
11B	267S10	Washer Flat M20	4
12	8S06H	Bolt M16 x 60	2
12A	267S09	Washer Flat M16	2
12B	17S08	Washer Spring M16	2
12C	7S06	Nut M16	2
13	CR530039	Bearing Stop	1
14	11S06H	Screw Set M16 x 50	1
14A	267S09	Washer Flat M16	1
14B	17S08	Washer Spring M16	1
14C	7S06	Nut M16	1

# RP850XD LOADER RUNWAY ASSEMBLY



The length of the intermediate loader track sections are contract specific items and a full description including the length must be given when ordering replacements

# RP850XD LOADER RUNWAY


1	CR299114	Combined Motor Brake & Gear Unit	1
4	CR269161	Motor Bedplate	1
5	CR21100101	Rope Drum	1
6	CR21100102	Rope Drum Motor Side	1
7	CR151096	Rope Drum Shaft Support Bearing	1
8	CR630244	Shaft Locking Collar	1
9	57S07F1	Screw Grub M12 x 16	3
10	CR569028	Loctite Fluid	1
13	CR52100119	Rope Drum Shaft	1
16	61S07	Nut Binx M20	4
17	8S07N	Bolt M20 x 90	4
17A	267S10	Washer Flat M20	4
18	8S06H	Bolt M16 x 60	2
18A	267S09	Washer Flat M16	2
18B	17S08	Washer Spring M16	2
18C	7S06	Nut M16	2
20	CR329072	Key Parallel 18 X 11 X 40	1
21	CR329092	Key Parallel 18 X 11 X 100	2
26	CR530587	Rope Anchor Bolts (Special)	2
27	CR229083	Limit Switch	1
27A	8S01C	Limit Switch Retaining Bolts M5	4
27B	17S02	Washer Spring M5	4
27C	267S03	Washer Spring M5	4
27D	7S01	Nut M5	4
28	CR54100788	Bracket Limit Switch	1
28A	11S03C	Screw Set M8 x 25	2
28B	105S02	Washer Tapered M8	2
28C	267S05	Washer Flat M8	2
28D	59S12	Nut Nyloc M8	2
29	CR229178	End Stop Limit Switch (Not Illustrated)	2
33	CR260336L	Guide Rail LeftHand	1
33A	CR260336R	Guide Rail Right Hand	1
34	CR620006	Caution Plate	2
35	11S02B	Screw Set M6 X 20	8
35A	267S04	Washer Flat M6	16
35B	17S03	Washer Spring M6	8
35C	7S02	Nut M6	8
36	CR530599	Hopper Safety Bolt & Chain	2
37	CR26100115	Bearing Support Angle	1
38	CR53100125	Runway, Opposite Winch Unit Side	1
39	CR53100124	Runway, Winch Unit Side	1
40	CR530592	Winch Unit Support Channel	1
41	CR261099	Runway Cross Tie	1
42	CR260358	Winch Unit Support Angle	1
43	CR530594	LH & RH Runway Tie Channels	2
44	CR53100128	Runway, Bottom Support Assembly	1
45	CR53100127	Loader Tie	1
46	CR530039	Bearing Stop	1
47	11S06H	Screw Set M16 x 50 Bearing Stop	1
47A	267S09	Washer Flat M16	1
47B	17S08	Washer Spring M16	1
47C	7S06	Nut M16	1

## RP850XD LOADER RUNWAY

48	CR530597	Runway GussetPlate	2
49	52S05G	Gusset Plate C/Sunk Screw Set M12 x 35	16
49A	267S07	Washer Flat M12	16
49B	17S06	Washer Spring M12	16
49C	7S05	Nut M12	16
50	11S06T	Bottom Support-Mixer Screw Set M16 x	8
50A	267S09	Washer Flat M16	16
50B	17S08	Washer Spring M16	8
50C	7S06	Nut M16	8
51	52S05G	Bottom Support-Runway C/Sunk Sets M12 x 35	4
51A	267S07	Washer Flat M12	4
51B	17S06	Washer Spring M12	4
51C	7S05	Nut M12	4
52	11S06H	Runway Tie Channel Screw Set M16 x 50	8
52A	267S09	Washer Flat M16	8
52B	17S08	Washer Spring M16	8
52C	7S06	Nut M16	8
53	11S06F	Runway Tie Screw Set M16 x 40	8
53A	267S09	Washer Flat M16	8
53B	17S08	Washer Spring M16	8
53C	7S06	Nut M16	8
54	11S06G	Winch Support Channel Screw Set M16 x 45	4
54A	267S09	Washer Flat M16	4
54B	17S08	Washer Spring M16	4
54C	7S06	Nut M16	4
55	11S06F	Runway Cross Tie Screw Set M16 x 40	4
55A	267S09	Washer Flat M16	4
55B	17S08	Washer Spring M16	4
55C	7S06	Nut M16	4
56	11S06H	Winch Support Angle Screw Set M16 x 50	4
56A	267S09	Washer Flat M16	4
56B	17S08	Washer Spring M16	4
56C	7S06	Nut M16	4
57	11S06H	Loader Tie Angle Screw Set M16 x 50	2
57A	267S09	Washer Flat M16	2
57B	17S08	Washer Spring M16	2
57C	7S06	Nut M16	2
58	52S05J	Winch Support Angle C/Sunk Set M12 x 45	2
58A	267S07	Washer Flat M12	2
58B	17S06	Washer Spring M12	2
58C	7S05	Nut M12	2
59	52S05G	Guide Rail C/Sunk Screw Sets M12 x 35	8
59A	267S07	Washer Flat M12	8
59B	17S06	Washer Spring M12	8
59C	7S05	Nut M12	8
60	N.P.N	LH & RH Intermediate Runway Sections Quote length and section dimensions	2
61	CR530630	Lifting Eyes (Weldable)	2



# RP850XD ARRANGEMENT OF WEIGHER & LOADING HOPPER




# RP850XD ARRANGEMENT OF WEIGHER & LOADING HOPPER

1	CR260338	Runway Opp. Limit Switch Side	1
2	CR260338	Runway Limit Switch Side	1
3	CR260062	Runway Hinge Pin	2
4	52S06G	Runway Hinge Pin C/Sunk Bolts M16 x35	4
4A	267S09	Washer Flat M16	4
4B	17S08	Washer Spring M16	4
4C	7S06	Nut M16	4
5	CR260334	Bridge	1
6	11S06G	Bridge Screw Sets M16 x 45	8
6A	267S09	Washer Flat M16	8
6B	17S08	Washer Spring M16	8
6C	7S06	Nut M16	8
7	CR220005	Limit Switch, NLA use CR229083	1
8	CR220100	Limit Switch Arm, NLA use CR229083	1
9	CR530450	Limit Switch Plate	1
10	52S05H	Limit Switch Plate C/Sunk Screws M12 x 40	4
10A	17S06	Washer Spring	4
10B	7S05	Nut	4
11	8S03D	Limit Switch Securing bolts (for CR220100) M8 x 40	4
11A	267S05	Washer Flat M8	8
11B	17S04	Washer Spring M8	4
11C	7S03	Nut M8	4
11D	8S01D	Limit Switch Securing bolts (for CR229083) M5 x 40	4
11E	17S02	Washer Spring M5	4
11F	7S01	Nut M5	4
12	CR260065	Hopper stop	1PR
13	CR260335	Runway Tie	1
14	8S06D	Runway Tie Bolts M16 X 40	4
14A	267S09	Washer Flat M16	4
14B	17S08	Washer Spring M16	4
14C	7S06	Nut M16	4
15	CR260337	Runway Brace	2
15A	8S06D	Runway Brace Bolts M16 X 40	4
15B	267S09	Washer Flat M16	4
15C	17S08	Washer Spring M16	4
15D	7S06	Nut M16	4
16	52S06J	Runway Brace C/Sunk Screws M16 x 45	4
16A	267S09	Washer Flat M16	4
16B	17S08	Washer Spring M16	4
16C	7S06	Nut M16	4
17	8S08T	Link Bolts M24 x 140	6
17A	267S12	Washer Flat M24	14
17B	17S11	Washer Spring M24	8
17C	7S08	Nut M24	6
18	CR180014	Rubber Bearing Silentbloc	8
19	CR260063	Link	4
20	CR260154	Weigher Frame	1
21	CR260064	Torque Tube (state machine number)	1
22	8S06G	Torque Tube Bolts M16 x 55	4
22A	267S09	Washer Flat M16	4
22B	17S08	Washer Spring M16	4
22C	7S06	Nut M16	4
23	CR260336L	Guide Rail Left Hand	1

# RP850XD ARRANGEMENT OF WEIGHER & LOADING HOPPER

23A	CR260336R	Guide Rail Right Hand	1
24	11S05F	Guide Rails Screw Set M12 X 40 (Lower)	4
24A	267S07	Washer Flat M12	4
24B	17S06	Washer Spring M12	4
24C	7S05	Nut M12	4
25	CR530600	Guide Rail Packings	4
30	52S05J	Guide Rails C/Screw M12 X 45 (Upper)	4
30A	267S07	Washer Flat M12	4
30B	17S06	Washer Spring M12	4
30C	7S05	Nut M12	4
40	8S06D	Runway Bolts M16 X 40	4
40A	267S09	Washer Flat M16	4
40B	17S08	Washer Spring M16	4
40C	7S06	Nut M16	4
41	52S06G	Runway C/Sunk Bolts M16 x35	4
41A	267S09	Washer Flat M16	4
41B	17S08	Washer Spring M16	4
41C	7S06	Nut M16	4
51	CR540344	Limit Swtich Striker	1
52	CR541293	Loading Hopper (550/850)	1
53	CR520131	Loading Hopper Front Axle	1
54	CR21100097	Loading Hopper Front Axle Roller	2
55	CR150844	Loading Hopper Front Axle Roller Bearing	2
56	CR520132	Rear Axle	1
57	CR210157	Rear Axle Roller	2
58	CR210160	Rear Axle Rope Pulley	2
58A	267S13	Waher Flat, M48 Rope Pulley	2
59	CR630209	Rear Axle Collar	2
59A	57S05D2	Screw Grub Rear Axle Collar M8 x 10	3
60	8S05L	Rear Axle Bolts Short M12 x 75	2
60A	17S06	Washer Spring M12	2
60B	7S05	Nut M12	2
61	8S05N	Rear Axle Bolts Long M12 X 90	4
61A	17S06	Washer Spring M12	4
61B	7S05	Nut M12	4
62	10S43	Rear Axle Flat Washer 1.5"	2
63	44S06L	Rear Axle Split Pin	2
64	CR350008	Hopper Rope (when ordering quote machine no:)	1
65	CR530602	Front Axle Washer	2
66	CR260436	Front Axle Rope Guide	2
67	CR530603	Front Axle Rope Retainer Block	2
68	CR530587	Front Axle Rope Anchor Bolts (Special)	4
69	8S05L	Front Axle Rope Anc. Guide Bolts M12 x 75	6
69A	17S06	Washer Spring M12	6
69B	7S05	Nut M12	6
70	CR639010	Collar, Rope Pulley Retaining	1
FIXINGS FOR ELECTRONIC LOADCELL (NOT ILLUSTRATED)			
71	8S06D	Bolts M16 X 40	4
71A	267S09	Washer Flat M16	4
71B	17S08	Washer Spring M16	4
71C	7S06	Nut M16	4
ELECTRONIC LOADCELL & DIGITAL READOUT BOX (NOT ILLUSTRATED)			
72	CR179022	Loadcell	1
73	CR179028	Indicator, Digital Readout Box	1


RP850XD WHIRLER ASSEMBLY (MOTOR UP)



## RP850XD WHIRLER ASSEMBLY (MOTOR UP)

1	CR520520	Whirler Shaft	1
2	CR261471	Bearing Housing	1
2A	131S01	Nipple Grease	1
2B	176S01	Cover Nipple Grease	2
3	CR532110	Bearing Cap	2
4	CR532111	Bearing Cap	1
5	CR532109	Spacer	1
6	CR569014	Lip Seal	1
7	CR569016	Lip Seal	1
8	CR150701	Bearing	1
9	CR150538	Bearing	1
10	68S05G	Cap Screw M10 x 40	1
11	CR219006	Blade Square Whirler, Cast	3
11	CR219006SS	Blade Square Whirler, Stainless Steel	3
11	CR219006SSA	Blade Square Whirler, Stainless Steel, Angled	3
11	CR219006H	Blade Square Whirler, Tungsten Carbide Coated	3
11	CR219006AH	Blade Square Whirler, Tungsten Carbide Coated Angled	3
11	CR219017	Blade Square Whirler, Two Blades, Tungsten Coated	A/R
12	CR532112	Mounting Angle	1
13	CR539005	Retaining Washer	3
14	11S05F	Screw Set M12	1
15	17S06	Washer Spring M12	1
16	CR269211	Whirler Mounting Bracket	1
17	CR220102	Motor	1
18	CR269212	Bracket Motor Mounting	1
19	CR340550	Pulley Whirler	1
20	CR340551	Bush Taperlock	1
21	CR340552	Pulley Motor	1
22	CR340546	Bush Taperlock	1
23	CR169002	V Belts	1
24	CR519151	Belt Guard	3
25	CR329001	Key Parrallel 18 x 11 x 60	1
26	CR329000	Key Parrallel 12 x 8 x 60	3
27	11S05M	Screw Set Motor Adjusting M12 x 70	2
28	7S05	Nut M12	2
30	11S05F	Screw Blade Retaining M12	3
31	7S05	Nut M12	3


RP850XD WHIRLER ASSEMBLY (MOTOR UP 460V 3PH 60HZ)



# RP850XD WHIRLER ASSEMBLY (MOTOR UP 460V 3PH 60HZ)

1	CR520520	Whirler Shaft	1
2	CR261471	Bearing Housing	1
2A	131S01	Nipple Grease	1
2B	176S01	Cover Nipple Grease	2
3	CR532110	Bearing Cap	2
4	CR532111	Bearing Cap	1
5	CR532109	Spacer	1
6	CR569014	Lip Seal	1
7	CR569016	Lip Seal	1
8	CR150701	Bearing	1
9	CR150538	Bearing	1
10	68S05G	Cap Screw M10 x 40	1
11	CR219006	Blade Square Whirler, Cast	3
11	CR219006SS	Blade Square Whirler, Stainless Steel	3
11	CR219006SSA	Blade Square Whirler, Stainless Steel, Angled	3
11	CR219006H	Blade Square Whirler, Tungsten Carbide Coated	3
11	CR219006AH	Blade Square Whirler, Tungsten Carbide Coated Angled	3
11	CR219017	Blade Square Whirler, Two Blades Tungsten Coated	A/R
12	CR532112	Mounting Angle	1
13	CR539005	Retaining Washer	3
14	11S05F	Screw Set M12	1
15	17S06	Washer Spring M12	1
16	CR269211	Whirler Mounting Bracket	1
17	CR229086	Motor Electric 460 Volt 3Ph 60Hz	1
18	CR269213	Bracket Motor Mounting	1
19	CR340550	Pulley Whirler	1
20	CR340551	Bush Taperlock	1
21	CR340552	Pulley Motor	1
22	CR340546	Bush Taperlock	1
23	CR169002	V Belts	1
24	CR519151	Belt Guard	3
25	CR329001	Key Parallel 18 x 11 x 60	1
26	CR329000	Key Parallel 12 x 8 x 60	3
27	11S05M	Screw Set Motor Adjusting M12 x 70	2
28	7S05	Nut M12	2
30	11S05F	Screw Blade Retaining M12	3
31	7S05	Nut M12	3

RP850XD SPLIT SHAFT WHIRLER





# RP850XD SPLIT SHAFT WHIRLER ASSEMBLY


1	CR529154	Whirler Top Shaft	1
2	CR529155	Whirler Lower Shtft	1
3	CR269163	Bearing Housing	1
3A	131S01	Nipple Grease	2
3B	176S01	Cover Nipple Grease	2
4	CR532110	Bearing Cap Upper	1
5	CR532111	Bearing Cap Lower	1
6	CR532109	Spacer Bearing	1
7	CR569014	Lip Seal Upper	1
8	CR569016	Lip Seal Lower	1
9	CR150701	Bearing	1
10	CR150538	Bearing	1
11	68S05G	Cap Screw M12 x 40	6
12	CR219006	Blade Square Whirler, Cast	3
12	CR219006SS	Blade Square Whirler, Stainless Steel	3
12	CR219006SSA	Blade Square Whirler, Stainless Steel, Angled	3
12	CR219006H	Blade Square Whirler, Tungsten Carbide Coated	3
12	CR219006AH	Blade Square Whirler, Tungsten Carbide Coated, Angled	3
12	CR219017	Blade Square Whirler, 2 Blades, Tungsten Coated	A/R
13	CR539005	Retaining Washer	1
14	11S05F	Screw Set M12	1
15	17S06	Washer Spring M12	1
16	CR239026	Coupling Rigid	1
16A	11S06L	Screw Set M16	6
16B	17S08	Washer Spring M16	6
17	CR220102	Motor Electric	1
17A	8S05G	Bolt M12	4
17B	7S05	Nut M12	4
17C	17S06	Washer Spring M12	4
17D	267S07	Washer Flat M12	4
18	CR269180	Bracket Motor Bedplate	1
19	CR340550	Pulley	1
20	CR340551	Bush Taperlock	1
21	CR340552	Pulley	1
22	CR340546	Bush Taperlock	1
23	CR160060	V Belts	3
24	CR549137	Belt Guard	1
25	CR329001	Key Parallel 18 X 11 X 60	1
26	CR329000	Key Parallel 12 X 8 X 60	1
27	11S05M	Bolt Belt Adjusting M12 x 70	2
28	7S05	Nut M12	2
29	CR539166	Support Strut	1
30	11S05F	Screw Blade Retaining M12	3
31	7S05	Nut M12	3

## **CROKER LOADER**

### **WIRE ROPE RENEWAL PROCEDURE**

1. Place the Hopper on the hopper stops. Loosen nut from rope anchor bolt, item 1, on one rope drum only, item 2.
2. Remove end of old wire rope from anchor bolt.
3. Fit end of new wire rope to anchor bolt and tighten nut.
4. Lay other end of new wire rope end to end with old wire rope removed in part 2. Bind both ends together with sticky tape (electrical or masking tape).
5. Carefully pull on the old wire rope to pull the new wire down to the bottom of the hopper and around the rear axle rope pulley, item 3, and up through the front axle rope guide, item 4.
6. Remove front axle rope retainer blocks, items 5 and 6, and slide onto the new rope.
7. Continue to pull the wire and thread through the second rope guide, item 7, and down around the second rope pulley, item 8, and up to the second rope drum, item 9.
8. Remove old wire from second anchor bolt, item 10, on second rope drum, item 9, and remove tape from ends of old and new wire.
9. Fit second end of new wire to second anchor bolt, item 10, on second rope drum, item 9.
10. Tighten anchor bolt nuts on both rope drums.
11. The new wire should now run over the front edges of both rope drums and down to front edges of both the lower axle rope pulleys, items 3 and 8, and up the back of the rope pulleys to the rope guides, items 4 and 7, with both rope retainer blocks, items 5 and 6, located on the section of wire rope between the two rope guides at the back of the hopper.
12. Start and stop the loader by hand, using the start and stop buttons, and take out all the slack of the wire rope in the raise direction (see important note on page 30), ensuring that the wire slots into both axle rope pulleys, item 2 and 9, and that the wire has wound evenly onto both rope drums. Make sure the hopper is level and sitting on weigher track stops before

# RP850XD WIRE ROPE RENEWAL PROCEDURE



positioning rope retainer blocks, items 5 and 6, approximately 2 inches (50 mm) in board of rope guides, item 4 and 7, each side and make fast retainer blocks onto wire.


13. Check that both limit switches are working correctly and the magnetic brake applies correctly.
14. Make sure hopper clears both sides of rope drums at the top of its operation.

**NOTE:** Hopper reaches end of travel between rope drums.

### **IMPORTANT NOTE**

Ensure that the slack wire is taken up in the raise direction and not the lowering direction. If the rope is wound incorrectly in the reverse direction on to the rope drums the hopper will not stop at the upper limit switch. It will continue until it makes contact with the top of the structure and will continue to heave until the wire rope breaks, with the result , if both sides of the wire fail at the same time, that the hopper will drop to the bottom end of the skip track.

# RP850XD WIRE ROPE RENEWAL PROCEDURE BOTTOM DISCHARGE LOADER




## **CROKER BOTTOM DISCHARGE LOADER**

### **WIRE ROPE RENEWAL PROCEDURE**

Take care when replacing rope, wear suitable hand and eye protection.

1. Raise the Hopper and insert Safety Bolts, lower Hopper allowing Top Axle to rest on bolts.
2. Slacken Wire Rope.
3. Undo Fixed Anchor Point and release Rope.
4. Feed Rope through pulleys.
5. Unwind Rope from Drum, release Drum Anchor Bolt and carefully pull off the old wire rope.
6. Secure new Wire Rope into Drum Anchor Bolt and tighten securely, wind Rope onto Drum taking care that it is not twisted, trapped or distorted.
7. Feed Rope through Pulleys.
8. Secure Rope to Fixed Anchor Point.
9. Carefully take up all slack in the Rope.
10. Take weight of Hopper and remove Safety Bolts.
11. Check that limit switches are working correctly and the magnetic brake applies correctly.
12. Lower Hopper to bottom of Loader Runway.

# RP850XD 1 LITRE PNEUMATIC OILER



SEE PNEUMATIC CIRCUIT DIAGRAMS FOR DETAILS OF AIR HOSE, ADAPTORS, ELBOWS AND METERING VALVE

# **WIRE ROPES**

## **SAFETY NOTES**

### **ALWAYS**

Store and handle the wire rope correctly, wear protective gloves and eye protection.

Check the rope test certificate is still in date especially if the rope has been in storage also check that the certificate is applicable to the rope.

Remove the rope from any reel or coil correctly and without kinking.

Only use correct end terminations and rope anchors.

Ensure that the rope is correctly located and seated on the rope drum.

Ensure that the rope is correct for the application and only use good quality ropes from reputable suppliers.

Inspect the wire rope for damage, wear, corrosion or abuse at the start of each shift.

Keep the wire rope clean and maintained in accordance with the manufacturers instructions.

### **NEVER**

Try to shorten any wire rope by knotting.

Bend a wire rope over small radii.

Subject wire ropes to shock loadings.

Allow wire ropes to run over sharp edges or abrasive surfaces etc.

Subject wire ropes to extremes of temperature.



Use wire ropes with obvious signs of mechanical, corrosive or heat damage.

Use wire ropes that are worn, frayed, split or corroded.

## **STORAGE**

Store wire ropes in a clean well ventilated, dry location preferably undercover and protected from extremes of temperatures.

If site conditions are such that undercover storage is not possible cover the rope with a waterproof cover and support clear of the ground.

Rotate stored wire ropes, reels or coils regularly to prevent migration of the rope lubricant, particular in warm environments.

Be aware that subjecting wire ropes to extremes of temperature as can affect the in service performance, high storage temperatures can reduce the effective strength of the rope.

## **SAFETY**

Running wire ropes are hazardous and should be guarded or personnel should be prevented access to them whilst in motion.

Wire ropes develop broken strands during their working life which present a hazard to maintenance personnel, always wear suitable hand and eye protection when handling ropes.

Take care when unfastening a coiled rope as the inherent springiness when released may cause it to strike attendant personnel or other equipment causing damage or injury.

Take care when removing worn, damaged or failed ropes from equipment as they may be tightly coiled, grossly distorted and still retain their springiness.

## **IN SERVICE INSPECTION AND MAINTENANCE**

Wire ropes used for lifting operations should be regularly inspected by a competent person and inspection records kept upto date.

Inspections should not only concentrate on the rope but also extend to the condition of sheaves, drums, guides etc.


Decisions on whether a wire rope is suitable for continued service should only be made by a competent person.

**IF IN DOUBT REPLACE THE ROPE.**


# RP850XD 1 LITRE PNEUMATIC OILER

1	CR119159	Oiler Pneumatic 1 Litre Capacity Tank	1
2	11S02D	Screw Set, Oiler Retaining, Not Illustrated	2
3	267S04	Washer Flat, Not Illustrated	4
4	61S02	Nut Binx, Not Illustrated	2

# 180 LITRE WATER TANK



## AIR CONTROLS



# WATER TANK 180 LITRES

1	CR210153	Outlet Pipe	1
3	CR520205	Float Centre Spindle	1
4	CR520206	Float Guide Rod	1
5	CR520207	Fulcrum Pin	1
6	CR520202	Outlet Valve Spindle	1
7	CR520203	Indicator Adjusting Rod	1
8	CR530545	Indicator Guide Tube	1
9	CR479000	Indicator Rule	1
*	CR530546	Indicator Scale Stiffner	1
*	CR540502	Indicator Scale Support	1
10	CR210150	Indicator	1
11	CR660015	Guide Tube Bush	1
12	CR210149	Indicator Adjusting Rod Handle	1
13	CR630304	Collar	1
14	CR450026	Gauge Glass	1
15	CR540498	Gauge Glass Guard Bolt	1
16	CR510475	Gauge Glass Cover Rubber	1
17	CR260112	Gauge Glass Cover	1
18	CR240269	Gauge Glass Guard Bolt	1
19	CR540141	Gauge Glass Cover Support	1
20	CR243005	Connecting Clips	1
21	CR510329	Gauge Glass Connecting pipe	1
22	CR450003	Tank Body	1
23	CR450037	Tank Body Lid	1
24	CR450038	Float	1
25	CR560118	Outlet Pipe Joint	1
26	CR490025	Washrs	1
27	CR630302	Locating Collars	1
28	CR330058	Inlet Valve Lever Spring	1
29	CR210151	Inlet Valve lever	1
30	CR210152	Inlet Valve	1
*	CR570015	Inlet Valve Rubber	1
31	CR260445	Locking Plate	1
32	CR210029	Centre Bearing	1
33	CR200009	Centre Bearing Chain Pinion	1
34	CR210022	Centre Bearing Housing	1
35	CR540147	Chain Guide	1
36	CR200031	Adjusting Rod Chain Pinion	1
37	CR200058	Chain	1
38	CR540497	Chain Guard	1
39	CR210148	Inlet Valve Body	1
40	CR450039	Inet Valve Lever Spring Adjuster	1
41	CR560019	Outlet Valve Spindle Seal	1
*	CR490031	Outlet Valve Spindle Washer	1
42	CR330028	Outlet Valve Spring	1
43	CR520058	Outlet Valve Spindle Pin	1
44	CR530118	Link	1
45	CR520049	Link Pin	1
46	CR530095	Outlet Valve Spindle End	1
47	CR450006	Operating Handle	1
48	CR210154	Outlet Valve	1
49	CR570016	Outlet Valve Rubber	1

# WATER TANK 180 LITRES

54	CR520056	FULCRUM BOLT	1
55	CR530118	OPERATING LEVER PIVOT (AIR CONTROL)	1
56	CR629000	SERIAL NO PLATE	1
62	CR110306	AIR CYLINDER	1

\* NOT ILLUSTRATED


**PAGE INTENTIONALLY BLANK**

# 100 LITRE WATER FLOW METER AS SUPPLIED TO R.LICKLEY

1	CR709000	0-100 Litre Flow Meter c/w Reset Facility & Hose Tails	1
1A	153S09	Clamp 'U'	2
1B	17S04	Washer Spring	4
2	CR54100808	Bracket Meter Support	2
2A	11S03C	Screw Set M8 X 25	4
2B	267S05	Washer Flat M8	4
2C	17S04	Washer Spring	4
2D	7S03	Nut M8	4
3	129S06F	Hose Tail Elbow 1" 90'	2
4	135S06F	Hose Tail Elbow 1" 135'	1
5	110S7G	Hose Tail Straight 1"	1
6	112S12	Adaptor Unequal 1" Female x 3/4" Male	2
7	112S09	Adaptor Unequal 3/4" Female x 1/2" Male	2
8	110S04E	Hose Tail Straight 1/2"	1
9	V2003232	Worm Drive Clips	6
10	119S15	Adaptor Unequal 1" Male x 3/4" Male	2
11	100S04	Seal Bonded 1/2"	2
12	100S06	Seal Bonded 3/4"	2
13	450150000	Valve Ball 3/4"	2
14	93S06	Adaptor, Bulkhead 3/4"	2
15	CR54100809	Coupling Quick Release (Claw type, cast)	2
16	93S07	Adaptor, Bulkhead 1"	1
17	154S13	Adaptor Tee 1" Male x Male x Female	1
18	37S03BE	Hose Flexible 838MM Long	1
19	37S03BH	Hose Flexible 1850MM Long	1
20	37S03BB	Hose Flexible 762MM Long	1




**RP850XD 1.5" BSP WATER SPRAY PIPE**



# RP850XD 1.5" BSP WATER SPRAY PIPE

1	CR459069	Pipe Water Spray 1.5" B.S.P.	1
1A	CR459070	Back Nut (not illustrated)	2
1B	CR459039	Nozzle Spray Bar (not illustrated)	5


# ARRANGEMENT OF BOTTOM DISCHARGE LOADER



# RP850XD BOTTOM DISCHARGE LOADER RUNWAY ARRANGEMENT

1	CR089045	Loading Hopper Assembly	1
2	CR089046	loader Frame/Runway Assembly	1
3	CR089047	Loader Drive Assembly	1
4	CR359004	Rope Wire	1


# RP850XD BOTTOM DISCHARGE LOADING HOPPER



# RP850XD BOTTOM DISCHARGE LOADING HOPPER

1	CR54100527	Loading Hopper Assembly	1
2	CR089041	Axle Assembly	2
3	CR089042	Door Assembly	1
4	CR089043	Pulley Assembly	2
5	CR089044	Side Roller Assembly	4

# RP850XD AXLE ASSEMBLY BOTTOM DISCHARGE HOPPER




# RP850XD AXLE ASSEMBLY BOTTOM DISCHARGE HOPPER

1	CR529161	Axle Shaft	1
2	CR210015	Track Wheel	2
3	CR159015	Bearing	2
4	C539130	Axle Shaft Washer	2
5	8S06N	Bolt M16 x 90	3
6	17S08	Washer Spring M16	3
7	7S06	Nut M16	3




# RP850XD DOOR ASSEMBLY BOTTOM DISCHARGE HOPPER



# RP850XD DOOR ASSEMBLY BOTTOM DISCHARGE HOPPER

1	CR269238	Door Discharge	1
2	CR529162	Pivot Shaft	1
3	CR159017	Bearing	2
4	CR089040	Guide Shaft Assembly	1
5	11S05E	Screw Set M10 x 35	2
6	57S07F1	Screw Grub M12 x 16	2
7	7S05	Nut M10	4
8	17S05	Washer Spring M10	4


# RP850XD GUIDE SHAFT ASSEMBLY BOTTOM DISCHARGE HOPPER



# RP850XD GUIDE SHAFT BOTTOM DISCHARGE HOPPER

1	CR529163	Guide Shaft	1
2	CR210156	Guide Shaft Wheel	2
3	CR150844	Bearing	2
4	CR530602	Guide Shaft Washer	2
5	8S04J	Bolt M10 x 65	3
6	17S05	Washer Spring M10	3
7	7S04	Nut M10	3


# RP850XD PULLEY BOTTOM DISCHARGE HOPPER



# RP850XD PULLEY BOTTOM DISCHARGE HOPPER

1	CR219015	Pulley	1
2	CR159018	Bearing	2
3	CR529165	Spacer	1
4	CR529006	Bush	1
5	CR539218	Pulley Spacer	1
6	8S07EE	Bolt M20 x 160	1
7	17S09	Washer Spring M20	1

# RP850XD SIDE ROLLER BOTTOM DISCHARGE HOPPER




**NOTE**  
LIMIT SWITCH OPERATING LEVER ITEM 3 FACES:-  
DOWN FOR LOWER SIDEROLLERS  
UP FOR UPPER SIDE ROLLERS

# RP850XD SIDE ROLLER BOTTOM DISCHARGE HOPPER

1	CR26100531	Bracket Side Roller	1
2	CR449003	Side Roller	1
3	CR53100561	Limit Switch Lever	1
4	267S	Washer Flat M20	2
5	8S07Q	Bolt M20 x 110	1
6	11S04C	Screw Set M10 X 25	4
7	7S07	Nut M20	1
8	7S04	Nut M10	4
9	17S09	Washer Spring M20	1
10	17S05	Washer Spring M10	4



# RP850XD LOADER FRAME ASSEMBLY BOTTOM DISCHARGE HOPPER





**NOTE**  
ALWAYS INSERT SAFETY BOLTS ITEM 4 BEFORE  
WORKING UNDER HOPPER, REMOVE BOLTS  
BEFORE RESTARTING MIXER

# RP850XD LOADER FRAME BOTTOM DISCHARGE HOPPER

1	CR269239	Loader Frame Assembly	1
2	CR269240	Brace Top	1
3	CR62006/4	Plate Caution	2
4	CR530062	Safety Bolt	2
5	CR229083	Limit Switch	2
6	V2003598	Bolt M16 x 40	14
7	11S01F	Screw Set M5 x 40	8
8	11S02A	Screw Set M6 x 16	8
8A	267S04	Washer Flat M6	16
9	7S06	Nut M16	14
10	17S08	Washer Spring M16	14
11	17S02	Washer Spring M5	8
12	17S03	Washer Spring M6	8
13	105S07	Washer Tapered M16	2

# RP850XD LOADER DRIVE BOTTOM DISCHARGE HOPPER



# RP850XD LOADER DRIVE BOTTOM DISCHARGE HOPPER

1	CR269239	Loader Frame Assembly	1
2	CR299128	Gearbox Unit	1
3	CR239000	Drive Shaft Coupling	1
4	CR239001	Drive Shaft Coupling	1
5	CR239002	Standard Element	1
6	CR239003	Taper Lock Bush	3
7	CR239021	Taper Lock Bush	1
8	CR159005	Bearing	2
9	CR239045	Key	3
10	CR23905	Key	1
11	CR219005	Cable Drum	1
12	CR529042	Drive Shaft	1
13	CR269155	Rope Keep Bar	1
14	CR530064	Rope Anchor Bolts	2
15	CR269067	Shear Blocks	4
16	CR549131	Coupling Guard	1
17	CR539228	Shims	6
18	8S13R	Bolt M30 x 120	4
19	8S07F	Bolt M20 x 50	9
20	8S07N	Bolt M20 x 90	4
21	8S02B	Bolt M6 x 30	6
22	8S05F	Bolt M12 x 50	2
23	7S11	Nut M30	4
24	7S07	Nut M20	13
25	7S05	Nut M12	2
26	7S02	Nut M6	6
27	267S14	Washer Flat M30	4
28	17S09	Washer Spring M20	13
29	17S03	Washer Spring M6	6
30	17S06	Washer Spring M12	2
31	105S09	Washer Tapered M20	4

**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 6**

**ELECTRICAL SYSTEM**

## **ELECTRICAL INFORMATION**

1. The mixing pan and mixing star motors should be interconnected in the control to operate at the same time, as it is important that both are working before a mix is added. Ensure that suitable overloads are fitted. The mixing pan and mixing star rotate anti-clockwise when looking from the top.

**NOTE:** With motors 5.5 kw and above, use Star Delta Starters. Below this, use Direct on Line Starters.

2. When a loader is attached a direct on line reversing starter is required complete with suitable overloads. The loader winch rotates anti-clockwise looking from the rope drum end and when the raise button is pressed.

The upper and lower limit switches are positioned to break the electrical supply to the loader motor when the loading hopper is in the required position at the top and bottom of the runway.

3. The door control solenoid has to be energised when the mixer door is required in the open position.

It is advisable to mount the starters away from the machine on supports free from vibration.

4. **IMPORTANT NOTICE:** All work on plant electrics including control panel circuits to be under taken by a suitably qualified and competent electrical person. All wiring in exposed positions should be suitably protected or armoured cable and protected by a suitable earth leakage circuit breaker.


5. The Mixing Star Drive and Pan Drive should be interconnected in order to start in the following sequence:-

**Mixing Star Motor  
Pan Drive Motor**

6. When a Whirler is fitted the sequence should be:-

**Whirler Motor  
Mixing Star Motor  
Pan Drive Motor**

RP850XD TYPICAL LAYOUT OF STARTERS



**3KW PAN DRIVE**




**18.5KW STAR DRIVE**

**15KW WHIRLER**

# RP850XD WINCH MOTOR BRAKE WIRING

## FLENDER MOTORS ABOVE 4KW

### BRAKE WIRED ACROSS MOTOR 6 PIN TERMINAL BLOCK






THREE PHASE A.C. BRAKE CONNECTED  
ACROSS MOTOR TERMINALS. DIRECT-ON  
- LINE STARTING METHOD ONLY



# RP850XD WINCH MOTOR BRAKE WIRING

## FLENDER THREE PHASE BRAKE SEPARATELY SWITCHED (9 PIN TERMINAL BLOCK)



### MOTOR CONNECTIONS

UP TO AND INCLUDING 4.0KW DIRECT ON LINE  
STARTING

LINK W2 TO U2  
LINK U2 TO V2

ABOVE 4.0KW DIRECT ON STARTING

LINK W2 TO U1  
LINK U2 TO V1  
LINK V2 TO W1

ABOVE 4.0KW STAR DELTA STARTING


NO LINKING

# RP850XD FLENDER MOTOR WIRING DIAGRAM


MOTORS UPTO & INCLUDING 4.0Kw

SEE SEPARATE PAGE FOR MOTORS

5.5Kw AND ABOVE



**TO REVERSE DIRECTION  
OF ROTATION CHANGE  
OVER ANY TWO SUPPLY  
LEADS**



<u>SUPPLY</u>	<u>METHOD OF START</u>	<u>CONNECTION STAR</u>	<u>LINK</u>
415/3/50	DIRECT ON LINE		W2-U1
380/3/50			U2-V1
		L1 L2 L3	V2-W1


UPTO & INC 4.0Kw

# RP850XD FLENDER MOTOR WIRING DIAGRAM


## MOTORS 5.5Kw AND ABOVE ONLY

SEE SEPARATE PAGE FOR MOTORS

4.0Kw & BELOW



**TO REVERSE DIRECTION  
OF ROTATION CHANGE  
OVER ANY TWO SUPPLY  
LEADS**



**STAR DELTA STARTING  
NO LINKING REQUIRED**

<u>SUPPLY</u>	<u>METHOD OF START</u>	<u>CONNECTION DELTA</u>	<u>LINK</u>
415/3/50 380/3/50	DIRECT ON LINE		W2-U1 U2-V1 V2-W1

5.5Kw & ABOVE


**PAGE INTENTIONALLY BLANK**

**PAGE INTENTIONALLY BLANK**

# INTERLOCK DOOR MECHANISM

NOTE SUPPLY WITH FOLLOWING ITEMS

1. KEY STANDARD MLK100
2. DUST CAP MLM100



**CUSTOMERS OWN  
PANEL DRILL 2 X 9  
DIA ON 15 CENTRES**

**M6 BOLTS SUPPLIED**

**LOCKING PLATE TO BE FORMED OVER TO  
SECURE BOLTS HEADS AGAINST ROTATION**

**MLD-100FB**

**2 M8 TAPPED HOLES**

# MISTURA DOOR INTERLOCK MECHANISM

1	CR719072	Interlock Door MLD100FB	A/R
2	CR229093	Key MLK100A Code A	A/R
2A	CR229094	Key MLK100B Code B	A/R
2B	CR229124	Key MLK100C Code C	A/R
3	CR229125	Cap Dust MLM100	A/R

When ordering replacement keys quote code off Interlock Mechanism

**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 7**

**PNEUMATIC SYSTEM**



## **SHUTDOWN PROCEDURE – PNEUMATICS**

(This procedure to be read in conjunction with electrical procedure – see section six).

### **We Recommend**


A lockable dump valve be fitted in the feed line to our mixing equipment (see drawing below).

Prior to any maintenance, the mixing equipment must be isolated using the above padlockable shut off valve. When put to the dump position, air will be allowed to vent to atmosphere removing the potential stored energy hazard. With the system in this condition, the mixer door will open and discharge blade will lower.


### **Important**

Prior to entry into mixing pan, the air supply must be exhausted and isolated as above. Check door is fully open and the discharge blade rests upon pan base before commencing maintenance/cleaning. Also check that the pressure gauge reads zero.

Should blade or door remain up or partially closed, it is imperative that the cause is investigated and dealt with prior to entering mixing pan. See maintenance section.



# RP850XD 110 VOLT PNEUMATIC CIRCUIT






## RP850XD 110 VOLT PNEUMATIC CIRCUIT

1	CR119347	Shut Off Valve	1
1A	191S03	1/2"-1/2" BSP Male/Male Nipple Adaptor Tapered	1
2	CR110005	Air Service Unit/Regulator/Lubricator	1
2A	11S03C	Screw Set Air Unit/Regulator Retaining	4
2B	267S05	Washer Flat	8
2C	17S04	Washer Spring	4
2D	7S03	Nut	4
Available Spares For Air Service Unit as Follows:			
*	CR119373	Bowl Regulator	1
*	CR119374	Bowl Lubricator	1
*	CR119375	Filter Repair Kit	1
*	CR119376	Filter Element	1
*	CR119377	Lubricator Repair Kit	1
*	CR119378	Pressure Gauge	1
*	CR119379	Bracket Mounting	2
3	CR119261	1/2" BSP Male x 12mm Fem Push In Straight Adaptor	1
4	CR119265	1/2" BSP Male x 12mm Female Push In Elbow	1
5	CR119119	12mm Diameter Plastic Air Hose	A/R
Items 3A,4A & 5A are used if 8mm Air Hose is fitted between Regulator, Control Box & T Pieces			
3A	CR119208	M12 Female-M8 Female Straight Push In Reducer	1
4A	CR119208	M12 Female-M8 Female Straight Push In Reducer	1
5A	CR119133	8mm Diameter Plastic Air Hose	A/R
6	CR119190	Electric/Pneumatic Solenoid Control Box Single Acting 110 Volt	1
6A	CR119240	Electric/Pneumatic Solenoid Control Box Double Acting 110 Volt	1
6B	11S03C	Screw Set Control Box Retaining	4
6C	267S05	Washer Flat	8
6D	17S04	Washer Spring	4
6E	7S03	Nut	4
7	CR119264	3/8" BSP Male x 12mm Female Push In Elbow, Discharge Blade Cylinder, both ends	2
7A	CR119129	Alternative 3/8" BSP Male x 12mm Female Push In Straight Adaptor for Bottom End of Discharge Blade Cylinder, if required	
8	CR119265	1/2" BSP Male x 12mm Female Push In Elbow, Discharge Door Cylinder, both ends	2
8A	CR119261	Alternative 1/2" BSP Male x 12mm Female Push In Straight Adaptor for Discharge Door Cylinder, both ends	2
9	CR119267	12mm Tee Plastic Push In	2
10	CR110305	Pneumatic Cylinder Discharge Door	1
See overleaf for details of Discharge Door Magnetic Cylinder			
10A	CR110326	Seal Kit For Item 10	1
11	CR110304	Pneumatic Cylinder Discharge Blade	1
11A	CR110323	Seal Kit For Item 11	1
12	V2003253	Cable Tie Nylon Long (not illustrated)	A/R

# RP850XD PNEUMATIC CIRCUIT OILER

DISCHARGE FINGER BRACKETS



# RP850XD PNEUMATIC CIRCUIT OILER

1	CR119159	Oiler Pneumatic	1
2	CR119254	Tee Piece, Push In 8mm/8mm	1
2A	CR119208	Tee Piece, Push In 12mm/8mm, Alternative, if required	1
3	CR119133	Air Pipe 8mm	A/R
4	CR119341	Elbow Push In 8mm, 1/8" thread	1
5	CR119198	Reducer 1/8" BSP-1/4"BSPM	2
6	CR119199	Fitting Banjo Assembly	1
7	CR119193	Valve Mretering	1
8	CR119171	Adaptor Straight	1
9	CR119325	Elbow 6mm Push In-1/8" BSP	3
10	CR119372	Tee Piece, Push In 6mm/6mm	1
11	CR119307	Air Pipe 6mm	A/R

# RP850XD 110 VOLT PNEUMATIC CIRCUIT

13	V2003111	Cable Tie Nylon short (not illustrated)	A/R
14	CR119215	M12 Female- M12 Male Push In Elbow, if required	A/R

The following alternative items are used to reduce from 12mm diameter Air Hose to 8mm diameter Air Hose if required

CR119208	M12 Male - M8 Female Straight Push In Reducer	A/R
CR119133	8mm Diameter Plastic Air Hose	A/R

## Discharge Door Magnetic Cylinder

CR119381	Pneumatic Cylinder, Magnetic	1
CR119382	Switch Reed, Magnetic	1
CR119383	Bracket, Reed Switch	1

**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 8**

**MISCELLANEOUS**

## **MISCELLANEOUS**

### **8.1 NOISE DETAILS**

Measured in accordance with Directive 79/113EEC at four points around the machine at 1 metre radius and at a height of 1 metre the noise did not exceed 85db(a)LPA



# RP850XD PAN COVER FOR LOADER

1	CR059000	Pan Cover Assembly with Swinging Lid & Two Access Panels Used With Loader	1
Comprises of following items			
2	11S03A	Screw Set Cover Retaining M8 x 16	6
2A	11S03B	Screw Set Cover Retaining M8 x 20	2
3	17S04	Washer Spring M8	8
4	267S05	Washer Flat M8	8
5	CR059001	Cover c/w Access Panels	1
6	CR059002	Door Swinging	1
7	CR059003	Counterbalance Weight	2
8	54S07M	Pin Roll	2
9	8S05P	Bolt M12 x 100	2
10	267S07	Washer Flat M12	4
11	61S05	Nut Binx M12	2
12	CR059004	Access Cover	2
13	11S02B	Screw Set Hinge Retaining M6	8
14	267S04	Washer Flat M6	16
15	17S03	Washer Spring M6	8
16	7S02	Nut M6	8
17	10537A02	Catch Over Centre Lockable	2
18	10538A02	Catch Plate	2
19	11S01A	Screw Set Catch Retaining M5 x 16	8
20	267S03	Washer Flat M5	16
21	17S02	Washer Spring M5	8
22	7S01	Nut M5	8
23	106209000	Seal Strip Self Adhesive 3mm x 25mm	A/R

# RP850 PAN COVER FOR LOADER C/W REAR BOX WITH HINGED COVER, SWINGING LID, SAMPLING TUBE & FUNNEL

1	SCR014	Pan Cover Assembly for Loader c/w Rear Box with Hinged Lid, Swinging lid, Sampling Tube & Funnel, as supplied to Capital	1
---	--------	--	---

Comprises of following items

2	11S03A	Screw Set Cover Retaining M8 x 16	6
2A	11S03B	Screw Set Cover Retaining M8 x 20	2
3	17S04	Washer Spring M8	8
4	267S05	Washer Flat M8	8
5	CR059002	Door Swinging	1
6	CR059003	Counterbalance Weight	1
7	54S07M	Pin Roll	2
8	8S06U	Bolt M12 Drilled for Lynch Pin	2
9	902S02	Lynch Pin & Chain	2
10	SCR008	Funnel Assembly c/w Retaining Plate	1
11	11S03E	Screw Set Funnel Retaining M8 x 35	4
12	267S05	Washer Flat M8	8
13	17S04	Washer Spring M8	4
14	7S03	Nut M8	4
15	SCR012	Sampling Point	1


# RP850XD PAN COVER WITH FRAME & INLET FOR HANDLING 1 TONNE BULK BAGS

1	CR59012	Pan Cover Assembly with Two Doors & Inlet for Handling 1 Tonne Bulk Bags as supplied to Robert Lickley Holdings	1
---	---------	---	---

Comprises of following items

2	11S06D	Screw Set Cover Retaining M16 x 40	6
2A	17S08	Washer Spring M16	6
2B	7S06	Nut M16	6
4	86SB	Anti-Luce Toggles, Door Retaining	2
5	10538A02	Plate Catch	2
6	10537A02	Catch Overcentre, Door Retaining	2
6A	11S01AA	Screw Set M5 x 12, Catch & Plate Retaining	8
6B	267S03	Washer Flat M5	8
6C	17S02	Washer Spring M5	8
6D	7S01	Nut M5	8
7	SCR041	Frame, Bulk Bag Supporting	1
7A	11S06E	Screw Set Cover Retaining M16 x 35	12
7B	17S08	Washer Spring M16	12
7C	7S06	Nut M16	12

# PAN COVER ASSEMBLY USED WITH BOTTOM DISCHARGE LOADER



**PART No 790 9498/5F/1**

# RP850XD PANCOVER FOR USE WITH BOTTOM DISCHARGE LOADER

	CR7909498/5F/1	Pan Cover Assembly, use with Bottom Discharge Loader	1
1	CR7909498/5F/2-1	Pan Cover Section	1
2	CR7909498/5F/2-2	Pan Cover Section	1
3	CR7909498/5F/2-3	Pan Cover Section	1
4	CR7909498/5F/2-4	Pan Cover Section	1
5	CR7909498/5F/2-5	Door	1
6	CR7909498/5F/2-6	Door	2
7	CR7909498/5F/2-7	Support Plate	1
8	CR7909498/5F/2-8	Vent Pipe	1
9	CR7909498/5F/2-9	Pan Cover Section	1
10	CR7909498/5F/2-10	Support Plate	1
11	CR249121	Latch	3
12	CR569005	Sealing Strip	5MT

**PAGE INTENTIONALLY BLANK**

**PAGE INTENTIONALLY BLANK**

# RP850XD WASH DOWN FACILITY

1	N.P.N.	Cleanwell 2200 14-150 Cold Water Power Washer c/w Lance	1
2	8S03E	Screw Set M8 x 45	2
2A	11S03C	Screw Set M8 x 25	4
2B	267S05	Washer Flat M8	8
2C	17S04	Washer Spring M8	6
2D	7S03	Nut M8	6
3	97S03	Hose Clip	2



**OPERATING  
AND  
MAINTENANCE MANUAL**

**SECTION 9**

**ELECTRONIC LOADCELL & INDICATOR/  
READOUT BOX**

## SPECIFICATIONS

Power Requirements:	115 VAC 60 Hz (optional 230 VAC 50/60 Hz) powering a 12 VDC 300 mA wall plug-in UL/CSA listed power supply for the Desktop enclosure. 115 VAC 60 Hz (optional 230 VAC 50/60 Hz) at 0.1A for the NEMA 4X enclosure.
Battery Operation:	12 VDC input jack for operation from an external battery 12 volt, 1.6 Ah for 8 hours operation
Enclosure Size:	Desktop: 8.65" W x 6.5" H x 3" D NEMA 4X: 9.8" W x 7.3" H x 3.2" D
Operating Temperature:	14° to 104° F or -10° to +40° C
Display:	5-digit, 0.6" high, 7-segment red LED
Sensitivity:	0.7uV/graduation (0-3.3 mV/V), Class III
Signal Input Range:	1.0mV min. to 50 mV max.
Transducer Excitation:	8.0 VDC
Number of Load Cells:	8 each, 350 OHM minimum load cells
Load Cell Cable Length:	150' max.; 30' max w/o sense lines
Resolution:	1 part in 20,000 displayed - 1 part in 80,000 internal
Capacities:	1,000 to 10,000 divisions commercial Up to 99,999 divisions noncommercial
Graduation Value:	1, 2 or 5 x 1, 0.1, 0.01 or 0.001
Sample Rate:	1 to 12 samples per second selectable
Auto Zero Range:	0.5 or 1 through 9 graduations
Weighing Units:	Pounds, kilograms, ounces, grams or pounds/kilograms
Keyboard:	Membrane type with 21 keys

### STANDARD FEATURES:

- Keyboard or Push Button Tare
- Gross, Tare, Net Conversion
- Metric Conversion
- Bi-directional Serial Interface
- Dual Preset Weight Comparator or Checkweigher with Outputs
- Auto Shut-Off Feature
- Selectable Sleep Mode
- Selectable Filtering
- Selectable Automatic Power On

### OPTIONAL FEATURES:

- NEMA 4X Enclosure
- External Relay Box for Preset Weight Comparators or Checkweigher (desktop only)
- Internal Relay Board for Preset Weight Comparators or Checkweigher (NEMA 4X only)

## INSTALLATION

The Model 708 Weight Indicating Instrument is available in either a stainless steel desktop enclosure or a stainless steel NEMA 4X wall-mount enclosure. Determine which enclosure version you have and refer to the appropriate section for installation and interconnection.

## AUTO-ON




The AUTO-ON jumper J1, when connected, will cause the indicator to power on automatically whenever power is applied to the power input connector. If power is lost momentarily and then reapplied, the indicator will turn on without pressing the ON key. See Figure No. 9 for location.

## INTERNATIONAL/ DOMESTIC JUMPER (J14Int)


Install the International/Domestic jumper, J14, to comply with OIML requirements (see Figure No. 9). With J14 installed, the 708 will perform the following functions:

1. A "lamp test" will be performed on power-up.
2. The printout of keyboard tare will be designated as "PT."

Please note the installation precautions.



## DESKTOP ENCLOSURE



The 708 desktop enclosure may be mounted on a desktop or other smooth, flat, horizontal surface or it may be mounted on a wall. Refer to Figure No. 1 for a layout of the wall-mounting bolts. Regardless of the manner in which the 708 is installed, the location chosen should be free of temperature extremes and water. It should be in a location where the display is easily viewed and is not subject to direct sunlight. The indicator should be mounted such that it is within easy reach of the operator. If wall mounted, make certain that the structure and mounting bolts are of sufficient strength to support the 708.




Figure No. 1

All terminations to the Model 708 Desktop Weight Indicating Instrument are made at the rear panel of the instrument. Connections for the Load Cell input, the PWC output and the Serial I/O are all made via "D" subminiature connectors while the 12VDC power is connected using a jack connector. Figure No. 2 illustrates the layout of the connector panel.

external load. When selecting the relays make certain that they are of sufficient capacity to drive the external load. A setup selection determines whether the device is on or off below the preset value. Refer to Figure No. 5 for the layout of the PWC Output connector.




Figure No. 5

PIN NO.	FUNCTION
10	OVER/PWC1
2	UNDER/PWC2
1	ACCEPT
12	GROUND

## NEMA 4X ENCLOSURES

For desk mounting of the 708 in the NEMA 4X enclosure, it is necessary to order separately a "DESK-MOUNT" kit. Refer to Assembly Instruction for Desk-Mount Kit (8539-M097-O1) for mounting instructions.

The Model 708 in a NEMA 4X enclosure is normally mounted on the wall or some other vertical surface. The enclosure is attached to the wall with four (4) bolts. Refer to Figure No. 6 for the hole layout for the NEMA 4X enclosure.





Figure No. 6



certain that the location chosen is free from sudden changes in temperature and that the mounting surface is strong enough to support the enclosure while being close enough to provide the operator with easy access to the keyboard. Carefully locate the mounting hole locations on the wall then drill and install the anchor bolts. Attached the enclosure to the wall and securely tighten the retaining bolts.

Continue installation by opening the front cover on the instrument enclosure. Loosen all four (4) retaining screws and rotate each of the clips to the side. **DO NOT REMOVE THESE SCREWS.** Fully open the front cover exposing the internal printed circuit board.

### Load Cell Connection

Loosen the cable gland connector for the load cell cable. This gland connector is located on the bottom of the enclosure on the right-hand side. Refer to Figure No. 7 for an illustration of the connector layout.

Slip the single cable from the load cell or load cell junction box through the gland connector and into the enclosure. Remove 2 inches of the outer insulation jacket then remove 1/4 inch of insulation from each of the wires (either 4 or 6). Refer to Figure No. 8 for an illustration of the proper method of preparing and then connecting wires to the terminal blocks. Once the cable has been properly prepared, connect it to terminal block P4 on the main printed circuit board. Figure No. 9 shows the location of the terminal blocks on the main printed circuit board.




Figure No. 7

Locate the one for the load cell and connect the cable as shown. To install a wire in a terminal block, first press down on the release bar for the terminal, insert the wire into the terminal opening then release the bar locking the wire in place. Repeat this procedure until all of the wires and shield have been installed. NOTE! If the load cell cable does not contain sense leads, you must install plug-in jumpers at J2 and J3 to connect the sense inputs to the excitation leads on the PC board. If the load cell cable does contain sense leads, these jumpers must be removed and stored by placing them on one pin only.

### Printer Cable Installation

Loosen the gland connector adjacent to the power cable gland connector (see Figure No. 7). Remove 2 inches of the outer insulating jacket from the cable then remove 1/4 inch of insulation from each of the wires (see Figure No. 8). These wires are to be connected to terminal block P8 at the bottom edge of the printed circuit board. Refer to Figure No. 9 for the location of this terminal block.

To terminate the wires, first press down on the terminal release bar then insert the wire into the terminal opening and release the bar to lock the wire in place.




Figure No. 8

### Preset Weight Comparator/Checkweigher Logic Level Output

If you so choose, you may use the logic level outputs from your 708 indicator's preset weight comparators or checkweigher to control peripheral devices used to manage the flow of material or signal when the weight is within preset limits. Note that these outputs are at logic level and cannot drive external devices directly. Solid state relays can be used to accept the logic level output from the 708 and in turn drive the external device.





Figure No. 9

# KEYPAD FUNCTIONS

The 708 is equipped with a 21-key keypad. The keypad is used to enter commands and data. This section describes each key along with the function it performs. It will be helpful to refer either to Figure No. 12 or to the actual 708 keypad while reading this section.



The membrane keyboard is not to be operated with pointed objects (pencils, pens, fingernails, etc.). Damage to keyboard resulting from this practice will **NOT** be covered under warranty.




Figure No. 12

- |            |   |
|------------|---|
| I<br>ON    | <b>ON KEY</b><br>Pressing this key applies power to the 708 and turns on the display.   |
| OFF        | <b>OFF KEY</b><br>Pressing this key removes power from the 708 and turns the display off.   |
| ZERO       | <b>ZERO KEY</b><br>This key is used to reset the gross weight to zero. If the gross weight exceeds the preset limit for this key an error message will be displayed when the key is pressed. The zero limit may be set to either 4% or 100% of scale capacity during setup and calibration of the 708.  |
| G<br>GROSS | <b>GROSS KEY</b><br>This key is used to return the weight display to the Gross Weight mode. In the gross weight mode, the total of all weight placed on the scale since the display was zeroed is displayed. The GROSS annunciator beneath the display window is turned on to signal the display of gross weight.   |
| T<br>TARE  | <b>TARE KEY</b><br>This key is used to enter a tare weight of up to four (4) digits and can operate in one of two modes depending on the setup of the 708. If the push button tare feature was selected during the setup of the instrument, pressing this key will cause the 708 to enter the current gross weight as the new tare weight value and automatically enter the net weight mode. The NET annunciator will be turned on to indicate that the 708 is now displaying a net weight. If the push button tare feature was not selected, pressing the TARE key will cause the currently stored tare weight to be displayed and the TARE annunciator will be turned on. The numeric keys may be used to enter a new tare value and the ENTER key pressed to store the new value. Once the new tare value is entered the 708 will automatically enter the Net Weight mode indicated by turning on the NET annunciator. |

### NET KEY



Pressing this key will cause the 708 to enter the Net Weight mode where the weight displayed is the gross weight less the stored tare weight. The NET annunciator is turned on to show that the displayed weight is the net weight. Note that the 708 will only enter the Net Weight mode if a valid tare weight is currently stored.

### TEST KEY



The TEST key is used to conduct a test of all display and memory elements. The test consists of 4 cycles each lasting 2 seconds:


1. All vertical display segments on (no annunciators).
2. All horizontal display segments on (no annunciators).
3. All annunciators and decimal points on.
4. All display elements off.

### PRESET KEY



The PRESET key is used to enter the weight values for either the two preset weight comparators or for the checkweigher feature depending on which feature was selected during setup and calibration of the 708. If the Preset Weight Comparator feature was selected, the PWC1 annunciator will flash and the display will show the currently stored value for the number 1 preset weight comparator. If the value displayed is acceptable, press the ENTER key, otherwise, use the numeric keys to enter the new preset value and press the ENTER key. The PWC2 annunciator will now flash and the display will show the currently stored value for the number 2 preset weight comparator. As before, if the value displayed is acceptable, press the ENTER key, otherwise, use the numeric keys to enter the new value and press the ENTER key. If the Checkweigher feature was selected and the PRESET key pressed, the ACCEPT and UNDER annunciators will flash and the preset value for the minimum acceptable weight will be displayed. Press the ENTER key if the displayed value is correct or use the numeric keys and enter the new value and press the ENTER key. The ACCEPT and OVER annunciators will now flash and the display will show the minimum value of weight over the accepted range. As before, if the value shown is correct, press the ENTER key. If the value is incorrect, enter the new value and press the ENTER key to save it. Note that this value must be greater than the accept value. Remember that both the preset weight comparators and checkweigher functions operate on the absolute value of the weight ignoring the polarity. After the second preset value is entered, the 708 will return to normal operation.

### lb / kg KEY



Pressing this key will change the weighing units to the alternate units of measurement if selected during setup of the instrument. With pounds displayed (lb annunciator turned on) pressing this key will change the weighing units to kilograms (kg annunciator turned on). Note that this feature must be enabled during setup and calibration for this key to be operational.

### PRINT KEY




Pressing this key will initiate the transmission of weight data via the serial I/O port unless the continuous data output feature was enabled during setup and calibration or setup review. Note that if the continuous data output feature was selected, this key will be disabled.

### ENTER KEY



The ENTER key serves two purposes. First, when reviewing setup parameters, pressing the ENTER key will cause the current setting of the parameter to be displayed. Second, the ENTER key is used to signal the completion of the entry of data and causes the 708 to process the data entered.

### 0 THROUGH 9 KEYS



These keys are used to enter numeric data during the setup and calibration as well as during normal operation of the instrument.

# ANNUNCIATORS

Note that annunciators are turned on to indicate that the display is in the mode corresponding to the annunciator label or that the status indicated by the label is active. Some annunciators are flashed on and off to signal that the 708 is waiting for an input from the keypad for use by the feature indicated by the annunciator.

## **ZERO**

The ZERO annunciator is turned on to indicate that the weight is within +/- 1/4 division of the center of zero.

## **GROSS**

The GROSS annunciator is turned on to indicate that the displayed weight is the gross weight which is the total of all weight placed on the scale platform since the display was last reset to zero.

## **TARE**

The TARE annunciator is flashed on and off to show that the 708 is in the tare weight input mode and that the new tare weight value should be entered on the numeric keys.

## **NET**

The NET annunciator is turned on to show that the displayed weight is the net weight which is the gross weight less the tare weight.

## **PWC1**

The PWC1 annunciator is turned on to indicate that the displayed weight is equal to or greater than the weight value stored as preset number 1. Note that this annunciator is active only when the Preset Weight Comparator feature has been enabled.

## **PWC2**

The PWC2 annunciator is turned on to indicate that the displayed weight is equal to or greater than the weight value stored as preset number 2. Note that this annunciator is active only when the Preset Weight Comparator feature has been enabled.

## **STABLE**

The STABLE annunciator is identified with two small triangular shapes and is turned on when the weight display is stable. This means that the change in successive weight samples is less than the motion limits selected during setup and calibration of the 708.

## **UNDER**

The UNDER annunciator is located to the left of the weight display and is used to signal that the displayed weight is less than the minimum value of acceptable weight used in the Checkweigher feature. Note that this annunciator is active only when the Checkweigher feature is enabled.

## **ACCEPT**

The ACCEPT annunciator is located just above the weight display and is used to signal that the displayed weight is within the acceptable weight limits for the Checkweigher feature. That is, it is equal to or greater than the minimum acceptable weight and equal to or less than the maximum acceptable weight. Note that this annunciator is active only when the Checkweigher feature has been enabled.

## **OVER**

The OVER annunciator is located to the right of the weight display and is used to signal that the displayed weight is equal to or greater than the minimum value of over weight used in the Checkweigher feature. Note that this annunciator is active only when the Checkweigher feature has been enabled.

## **lb**

The lb annunciator is located to the right of the weight display and is turned on to show that the displayed weight units of measure is pounds.

## **kg**

The kg annunciator is located to the right of the weight display and is used to signal that the units of measurement for the displayed weight is kilograms.



# ERROR CODES

The 708 is equipped with software that detects when an error in operation takes place. The following lists the error code displays supported by the 708 along with their meaning. Should you encounter an error display, please refer to this list for the cause and corrective action.

UnSt

Motion is present when trying to power up, print, zero or perform a push button tare function. **CORRECTIVE ACTION:** wait for a stable weight display (STABLE annunciator on) before performing these operations.

UnLd

The weight on the scale exceeds the zero range when powering up. **CORRECTIVE ACTION:** remove the excess load from the scale then press the ZERO key. If the scale has not been calibrated previously, calibration should be completed before attempting further operation.

LoAd

The scale deadload is less than the zero range when powering up. **CORRECTIVE ACTION:** replace the scale platform or items normally on the scale when it was calibrated and press the ZERO key. If the scale has not been calibrated previously, calibration should be completed before attempting further operation.

-oF-

The 708 is attempting to display a positive number greater than 5 digits in length or a negative number of more than 4 digits. **CORRECTIVE ACTION:** return to the Gross Weight mode and review the Tare value.

-oL-

The load on the scale exceeds the scale capacity plus 9 divisions. **CORRECTIVE ACTION:** remove the over capacity load from the scale platform.

Err

An invalid keypad entry was attempted:

1. PRINT key pressed with a negative weight displayed.
2. TARE key pressed to enter a push button tare value of zero or a negative value.
3. ENTER key pressed to enter a tare weight value that exceeds scale capacity.
4. ENTER key pressed to enter a tare weight value that is inconsistent with the scale's division value. (i.e. attempt to enter a tare value of 123 with scale division value of 5).
5. ZERO key pressed when the gross weight is outside the scale zero weight range.
6. lb/kg key pressed to change to kilograms when the kilogram tare weight value exceeds 4 digits in length.

**CORRECTIVE ACTION:** determine which of the reasons for the error display is applicable then take the appropriate corrective action.

ErrA

The proper load cell signal is not getting to the signal processing circuit for one or more of the following possible reasons with corrective action:

The load cell output is below the indicator minimum input of 1.0mV. Consult your scale serviceman;

Sense lead jumpers are not installed for four (4) wire load cells. Install both SENS jumpers (see Figure No. 9);

The load cell wiring is incorrect. Check load cell connector wiring;

Load cell or circuit failure. Consult your scale serviceman.

Err1

A program checksum mismatch has been detected.  
CORRECTIVE ACTION: contact your scale serviceman.

Err2

A write command to the NOVRAM was attempted while the NOVRAM was in a protected mode (loss of control by program). CORRECTIVE ACTION: contact your scale serviceman.

Err3

RAM test failure. CORRECTIVE ACTION: contact your scale serviceman.

Err4

NOVRAM failure during startup. CORRECTIVE ACTION: contact your scale serviceman.

Err5

NOVRAM response failure. CORRECTIVE ACTION: contact your scale serviceman.

## MAINTENANCE

The maintenance on the Model 708 Weight Indicating Instrument should be limited to an occasional cleaning of the outside of the instrument enclosure. There are no user-serviceable components within the enclosure. To clean the enclosure and keyboard, use a soft cloth dampened with water. If you wish to use a detergent, make certain that it is safe and then use it sparingly. Do not wash the Desktop enclosure. Only the NEMA 4X version of the 708 may be washed down.

# PERFORMANCE SPECIFICATIONS

## Parameter

Rated Output	mV/V $\pm$ 0.25%
Combined Error	%*
Non-repeatability	%*
Creep (30 minutes)	%*
Temperature Effect on Zero Balance	%* / °C
Temperature Effect on Span	%* / °C
Compensated Temperature Range	°C
Operating Temperature Range	°C
Safe Overload	%*
Ultimate Overload	%*
Zero Balance	%*
Input Resistance	$\Omega \pm 30$
Output Resistance	$\Omega \pm 1.5$
Insulation Resistance	M $\Omega$ @ 100 V
Recommended Supply Voltage	V
Maximum Supply Voltage	V

## Units

mV/V $\pm$ 0.25%
%*
%*
%*
%* / °C
%* / °C
°C
°C
%*
%*
%*
$\Omega \pm 30$
$\Omega \pm 1.5$
M $\Omega$ @ 100 V
V
V

## LOAD CELL CAPACITY

### $\leq 7500$ kg

### $\geq 10000$ kg

2	2
< $\pm$ 0.05	< $\pm$ 0.1
< $\pm$ 0.025	< $\pm$ 0.03
< $\pm$ 0.05	< $\pm$ 0.05
< $\pm$ 0.0025	< $\pm$ 0.0025
< $\pm$ 0.008	< $\pm$ 0.008
-10 to +40	-10 to +40
-40 to +80	-40 to +80
150	150
300	300
< $\pm$ 1	< $\pm$ 1
380	380
350	350
> 5000	> 5000
10	10
15	15

\* WITH RESPECT TO RATED OUTPUT

## CABLE SPECIFICATIONS

4 m - Four core screened, 6mm dia. with polyurethane outer sheath

POSITIVE EXCITATION = RED  
NEGATIVE EXCITATION = BLUE

POSITIVE SIGNAL = GREEN  
NEGATIVE SIGNAL = YELLOW

## PHYSICAL DIMENSIONS (mm)

RANGE (kg)	A	B	C	D	E	F	G	H	J	K	L	M	Wt (kg)	Wt (kg)
500	125	84	42	42	13	M16 x 2	102	174	16	193	40	135	3	13.6
1000 to 7500	125	84	42	42	13	M24 x 2	102	174	16	193	40	135	3.6	13.6
10000 / 15000	175	110	55	64	21	none	148	238	21	243	48	175	8.8	22.5
20000 to 30000	175	110	55	64	27	none	148	238	21	243	50	175	9.3	23.6

(Cell)

(LA90)

